

IQ 100 Series (130/140/150)

Meter User & Installation Manual



Powering Business Worldwide

IM02601003E

Rev F

Copyright (c) 2011 by Eaton Corporation. All rights reserved.

Specifications contained herein are subject to change without notice.

Power Xpert and PowerVision are registered trademarks of Eaton Corporation.

**EATON CORPORATION - CONFIDENTIAL AND PROPRIETARY
NOTICE TO PERSONS RECEIVING THIS DOCUMENT AND/OR TECH-
NICAL INFORMATION.**

THIS DOCUMENT, INCLUDING THE DRAWING AND INFORMATION CONTAINED THEREON, IS CONFIDENTIAL AND IS THE EXCLUSIVE PROPERTY OF EATON CORPORATION, AND IS MERELY ON LOAN AND SUBJECT TO RECALL BY EATON AT ANY TIME. BY TAKING POSSESSION OF THIS DOCUMENT, THE RECIPIENT ACKNOWLEDGES AND AGREES THAT THIS DOCUMENT CANNOT BE USED IN ANY MANNER ADVERSE TO THE INTERESTS OF EATON, AND THAT NO PORTION OF THIS DOCUMENT MAY BE COPIED OR OTHERWISE REPRODUCED WITHOUT THE PRIOR WRITTEN CONSENT OF EATON. IN THE CASE OF CONFLICTING CONTRACTUAL PROVISIONS, THIS NOTICE SHALL GOVERN THE STATUS OF THIS DOCUMENT.

Table of Contents

Disclaimer of Warranties and Limitation of Liability	7
Support Services	9
Support Services	9
Website	9
EatonCare Customer Support Center	9
Technical Resource Center	10
European PanelMate Support Center	10
For Customers in Europe, contact:	10
Repair and Upgrade Service	10
Additional support is also available from our well-equipped	10
Repair and Upgrade Service (support for OI)	10
IQ 100 Series Meter Overview and Specifications	11
Hardware Overview	11
IQ 100 Series Meter / Digital Transducer	11
IQ 100 Series Digital Transducer	11
Voltage and Current Inputs	11
Universal Voltage Inputs	11
Current Inputs	12
Ordering Information	12
Measured Values	13
Programmable Values	13
Factory Settings	14
Utility Peak Demand (IQ140/150)	14
Specifications	15
Compliance	17
Accuracy	18
IQ 100 Series Mechanical Installation	19
Introduction	19
ANSI Installation Steps	20
DIN Installation Steps	21
IQ 100 Series Transducer Installation	22
IQ 100 Series Electrical Installation	23
Considerations When Installing Meters	23
CT Leads Terminated to Meter	24
CT Leads Pass-Through (No Meter Termination)	25
Quick Connect Crimp CT Terminations	26
Voltage and Power Supply Connections	27
Ground Connections	27
Voltage Fuses	27
Electrical Connection Diagrams	28

IQ 100 Series Communication Installation	41
RS485 / KYZ Output (Communication Option)	41
IQ 100 Series Transducer Communication Information	44
Meter Connection	44
Configuring the Ethernet Connection	44
Programming the IQ 100 Series Meter Using the Front Panel	49
Introduction	49
Understanding Meter Face Elements	49
Understanding Meter Face Buttons	49
Using the Front Panel	50
Understanding Startup and Default Displays	50
Using the Main Menu	51
Using Reset Mode	51
Entering a Password	52
Using Configuration Mode	53
Configuring the Scroll Feature	54
Configuring CT Setting	55
Configuring PT Setting	56
Configuring Connection Setting	57
Configuring Communication Port Setting	57
Using Operating Mode	59
Understanding the % of Load Bar	59
% of Load Segment Table	59
Performing Watt-Hour Accuracy Testing (Verification)	60
Programming the IQ 100 Series Meter Using Software	61
Overview	61
Connecting to the IQ 100 Series Meter/Transducer	61
Accessing the IQ 100 Series Device Profile	62
Performing Device Profile Tasks	63
Configuring Settings	64
Configuring Scaling	64
Functional Overview of CT and PT Ratios	64
Configuring Energy and Display Settings	65
Configuring Communication Settings	66
Configuring (System) Settings	66
Polling the IQ 100 Series Meter	67
Instantaneous Polling	67
Poll Power and Demand	68
Poll Phasors	69
Using the IQ 100 Series Tools Menu	70
Accessing the Device Profile Screen	70
Reset Device Information	70
Retrieve Device Status	70
Flash Update Firmware	70

Performing Additional Tasks with Eaton Meter Configuration Software	71
Using Connection Manager	71
Disconnecting from an IQ 100 Series meter	73
Changing the Primary Device/Address	73
Merging Connection Databases	73
Using the Options Screen	74
Using the Help Menu	74
App. A: IQ 100 Series Navigation Maps	75
Introduction	75
Navigation Maps (Sheets 1 to 4)	75
Main Menu Screens (Sheet 1)	76
Operating Mode Screens (Sheet 2)	77
Reset Mode Screens (Sheet 3)	78
Configuration Mode Screens (Sheet 4)	79
App.B Modbus Mapping for IQ 100 Series	81
Introduction	81
Modbus Register Map Sections	81
Floating Point Values	82
Important Note Concerning the IQ 100 Series Modbus Map	83
Modbus Register Map (MM-1 to MM-16)	

IQ 100 Series (130/140/150) Meter

Table of Contents

Disclaimer of Warranties and Limitation of Liability

The information, recommendations, descriptions and safety notations in this document are based on Eaton Corporation's ("Eaton") experience and judgment and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Eaton selling policies or other contractual agreement between Eaton and the purchaser. **THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.**

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein.

IQ 100 Series (130/140/150) Meter
Disclaimer of Warranties and Limitation of Liability

Support Services

Support Services

The goal of Eaton is to ensure your greatest possible satisfaction with the operation of our products. We are dedicated to providing fast, friendly and accurate assistance. That is why we offer you so many ways to get the support you need. Whether it's by phone, fax or e-mail, you can access Eaton's support information 24 hours a day, seven days a week. Our wide range of services is listed below.

You should contact your local distributor for product pricing, availability, ordering, expediting and repairs.

Website

Use the Eaton website to find product information. You can also find information on local distributors or Eaton's sales offices.

Website Address
www.eaton.com/electrical

EatonCare Customer Support Center

Call the EatonCare Support Center if you need assistance with placing an order, stock availability or proof of shipment, expediting an existing order, emergency shipments, product price information, returns other than warranty returns, and information on local distributors or sales offices.

Voice: 877-ETN CARE (386-2273) (8:00 am – 6:00 pm EST)
FAX: 800-752-8602

After-Hours Emergency: 800-543-7038
(6:00 pm – 8:00 am EST)

If you are in the US or Canada, and have OI or PLC questions, you can take advantage of our toll-free line for technical assistance with hardware and software product selection, system design and installation, and system debugging and diagnostics. Technical support engineers are available for calls during regular business hours.

Technical Resource Center

Voice: 877-ETN CARE (386-2273) (8:00 am – 5:00 pm EST)
FAX: (828) 651-0549
e-mail: TRC@Eaton.com

European PanelMate Support Center

This engineering company, located in Zurich, Switzerland, provides high-level quality support and repair assistance for your PanelMate products. You will receive technical and application support.

For Customers in Europe, contact:

BFA Solutions, Ltd.
Voice: +41 1 806 64 44 (9:00 am – 5:00 pm CET)
e-mail: gk@bfa.ch
www.bfa.ch

Repair and Upgrade Service

Additional support is also available from our well-equipped Repair and Upgrade Service department. If you have questions regarding the repair or upgrade of OI product, contact your local distributor.

Repair and Upgrade Service (support for OI)

Voice:
877-ETN-CARE (877-386-2273) (8:00 am – 5:00 pm EST)
414-449-7100 (8:00 am – 5:00 pm EST)
FAX: 614-882-3414
e-mail: TRC@eaton.com

IQ 100 Series Meter Overview and Specifications

Hardware Overview

The IQ 100 (IQ 130/140/150) is a multifunction power meter designed to be used in electrical substations, panel boards and as a power meter for OEM equipment. The unit provides multifunction measurement of most electrical parameters.

The unit is designed with advanced measurement capabilities, allowing it to achieve high performance accuracy. The IQ 100 meter is specified as a 0.5% class energy meter for billing applications as well as a highly accurate panel indication meter.

The IQ 100 meter provides a host of additional capabilities, including optional RS485 with Modbus RTU and RJ45 Ethernet connection with Modbus TCP communication.

IQ 100 meter features that are detailed in this manual are as follows:

- 0.5% Class Revenue Certifiable Energy and Demand (IQ 140/150) Metering
- Meets ANSI C12.20 (0.5%)
- Multifunction Measurement including Voltage, Current, Power, Frequency, Energy, etc.
- Field Upgrade without Removing Installed Meter
- Percentage of Load Bar for Analog Meter Perception
- Easy to Use Faceplate Programming
- RS485 or RJ45 Modbus Communication

The IQ 100 Series meter is available in two configurations: meter with integral display and transducer only.

IQ 100 Series Meter with Integral Display

Meter with integral display in one compact unit. Features an optional RS485 (Modbus RTU) and KYZ Pulse Output or optional RJ45 (Modbus TCP) Ethernet port and KYZ Pulse Output, and can be programmed using the faceplate of the meter. ANSI or DIN mounting may be used.

IQ 100 Series Digital Transducer (No display)

A Digital Transducer only unit providing KYZ Pulse Output and RS485 communication via Modbus RTU or Modbus ASCII protocols or optional RJ45 (Modbus TCP) Ethernet port and KYZ Pulse Output. The unit is designed to install using DIN Rail Mounting (see instructions on page 22).

Voltage and Current Inputs

Universal Voltage Inputs

Voltage Inputs allow measurement to 416 Volts Line-to-Neutral and 721 Volts Line-to-Line. This insures proper meter safety when wiring directly to high voltage systems. One unit will perform to specification on 69 Volt, 120 Volt, 230 Volt, 277 Volt, 277 Volt and 347 Volt power systems.

Current Inputs

The IQ 100 Series meter's Current Inputs use a unique dual input method:

- Method 1: CT Pass Through
The CT passes directly through the meter without any physical termination on the meter. This insures that the meter cannot be a point of failure on the CT circuit. This is preferable for utility users when sharing relay class CTs. No Burden is added to the secondary CT circuit.
- Method 2: Current Gills
This unit additionally provides ultra-rugged Termination Pass Through Bars that allow CT leads to be terminated on the meter. This, too, eliminates any possible point of failure at the meter. This is a preferred technique for insuring that relay class CT integrity is not compromised (the CT will not open in a fault condition).

Ordering Information

IQ - 150 - M - A - 6 - 5 - 1 - 1
1 2 3 4 5 6

1. Model:

130 = Volts/Amps Meter

140 = Power Meter

150 = Energy Meter

2. Meter Type

M = Meter (with integral display)

T = Transducer Only (no display, with either RS485 or RJ45 option)

3. Frequency:

5 = 50 Hz System

6 = 60 Hz System

4. Current Input:

5 = 5 Amp Secondary

1 = 1 Amp Secondary

5. Power Supply:

1 = Universal, (90 - 265) VAC @50/60Hz or (100-370) VDC

4 = (18 - 60) VDC

6. Communication

0 = None (see Programmable Settings and Factory Settings sections beginning on the next page)

1 = RS485 with Modbus RTU and KYZ Pulse Output

2 = RJ45 Ethernet connection with Modbus TCP and KYZ Pulse Output

Example: IQ 150-M-A-6-5-1-1

(IQ 150 Energy Meter with 60 Hz System, 5 Amp Secondary, 90-265 VAC/100-370 VDC Power Supply, RS485 Modbus and KYZ Pulse Output)

Measured Values

The following table lists the measured values available for the different IQ 100 Series models.

IQ 100 Series Feature Comparison			
Readings/Features	IQ 130	IQ 140	IQ150
Volts L-N	Yes	Yes	Yes
Volts L-N Max/Min	Yes	Yes	Yes
Volts L-L	Yes	Yes	Yes
Volts L-L Max/Min	Yes	Yes	Yes
Amps	Yes	Yes	Yes
Amps Neutral	Yes	Yes	Yes
Amps Max/Min	Yes	Yes	Yes
kW, +/-, Max/Min	No	Yes	Yes
kVAR, +/-, Max/Min	No	Yes	Yes
PF, +/-, Max/Min	No	Yes	Yes
kVA, Max./Min	No	Yes	Yes
Frequency	No	Yes	Yes
kWh	No	No	Yes
kVARh	No	No	Yes
kVAh	No	No	Yes
Energy Accumulators	No	No	Yes
Demand Values	No	Yes	Yes

Programmable Values

An IQ 100 Series meter that does not have either the RS485 or RJ45 communication options can only be programmed through the front panel. Not all meter settings are available through the front panel. The following table lists the programmable settings for meters with and without RS485 or RJ45 communication options.

COM Option	Scroll	CT Setting	PT Setting	Connection Type	Password Enable	Communication	Reset	Scaling -Energy and Power
With RS485/ RJ45	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Without RS485/RJ45	Yes	Yes	Yes	Yes	No	No	Yes*	No

* NOTES:

- Reset Energy is not available in a meter without RS485 or RJ45 communication option.
- Because a meter without RS485 or RJ45 communication option does not support password enabling, the Reset Max/Min/All commands are not password protected.

The next section lists the factory settings for the IQ 100 Meter. Without either the RS485 or RJ45 communication option, you won't be able to change some of these settings.

Factory Settings

The following table lists the default settings for the IQ 100 Series meter. The settings which cannot be changed via the front panel are noted; if the meter does not have the RS485 or RJ45 option, these settings cannot be changed at all.

Setting	Default Value	Configurable through Front Panel?
Power Scale	Auto	No
Energy Digits	8	No
Energy Decimal Places	0	No
Energy Scale	kilo (k)	No
Power Direction	View as Load	No
Demand Averaging Method	Fixed	No
Demand Averaging Interval	15 (minutes)	No
Demand Averaging Sub-interval	None	No
Auto-Scrolling Display	Yes	Yes
Display Configuration	Volts L-L, Volts L-N, Amps, W/VAR/PF, VA/Hz, Wh, VARh, VAh	No
CT Numerator	1 (for 1Amp model) or 5 (for 5 Amp model)	Yes
CT Denominator	1 (for 1Amp model) or 5 (for 5 Amp model)	Not changeable through software or front panel
CT Multiplier	1	No
PT Numerator	120	Yes
PT Denominator	120	Yes
PT Multiplier	1	Yes
System Wiring	3 Element Wye	Yes
Phases Displayed	ABC	No
RS485 COM Address	1	Yes*
RS485 COM Protocol	Modbus RTU	Yes*
RS485 COM Baud Rate	57600	Yes*
RS485 COM Response Delay	0	No*
IP Address	10.0.0.1	No**
Subnet Mask	255.255.255.0	No**
Ethernet Option Baud Rate	57600	No**
Ethernet Option Protocol	Modbus TCP	No**
Password	Disabled	No

* If the meter does not have the RS485 option, these settings do not apply.

** If the meter does not have the RJ45 Ethernet option, these settings do not apply.

Utility Peak Demand (IQ140/150)

The IQ 100 Series meter provides user-configured Fixed Window or Sliding Window Demand. This feature allows you to set up a Customized Demand Profile. Fixed Window Demand is demand used over a user-configured demand period (usually 5, 15 or 30 minutes). Sliding Window Demand is a fixed window demand that moves for a user-specified subinterval period. An example of Sliding Window

Demand is a 15-minute demand using 3 subintervals and providing a new demand reading every 5 minutes, based on the last 15 minutes.

Utility Demand Features can be used to calculate kW, kVAR, kVA and PF readings. All other parameters offer Max and Min capability over the user-selectable averaging period. Voltage provides an Instantaneous Max and Min reading which displays the highest surge and lowest sag seen by the meter.

Specifications

Power Supply

- Range: 1 Option: Universal, (90 to 265) VAC @50/60Hz or (100 to 370) VDC
- Power Consumption: 4 Option: (18-60) VDC
- Power Consumption: 5 VA, 3.5W

Voltage Inputs (Measurement Category III)

- Range: Universal, Auto-ranging up to 416VAC L-N, 721VAC L-L
- Supported hookups: 3 Element Wye, 2.5 Element Wye, 2 Element Delta, 4 Wire Delta
- Input Impedance: 1M Ohm/Phase
- Burden: 0.0144VA/Phase at 120 Volts
- Pickup Voltage: 10Vac
- Connection: Screw terminal (Figure 3.4)
- Max Input Wire Gauge: AWG#12 / 2.5mm²
- Fault Withstand: Meets IEEE C37.90.1
- Reading: Programmable Full Scale to any PT Ratio

Current Inputs

- Class 10: 5A Nominal, 10A Maximum
- Class 2: 1A Nominal, 2A Maximum
- Burden: 0.005VA Per Phase Max at 11 Amps
- Pickup Current: 0.1% of Nominal
- Connections: O or U Lug Electrical Connection
Pass-through Wire, 0.177" / 4.5mm Maximum Diameter
Quick Connect, 0.25" Male Tab
- Fault Withstand (at 23°C): 100A/10sec., 300A/3sec., 500A/1sec.
- Reading: Programmable Full Scale to any CT Ratio

Isolation

- All Inputs and Outputs are galvanically isolated to 2500 VAC

Environmental Rating

- Storage: (-20 to + 70)° C
- Operating: (-20 to + 70)° C
- Humidity: to 95% RH Non-condensing
- Faceplate Rating: NEMA12 (Water Resistant), Mounting Gasket Included

Measurement Methods

- Voltage, Current: True RMS
- Power: Sampling at 400 + Samples per Cycle on All Channels
Measured Readings Simultaneously
- A/D Conversion: 6 Simultaneous 24 bit Analog to Digital Converters

Update Rate

- Watts, VAR and VA: 100 milliseconds (Ten times per second)
- All other parameters: 1 second

Communication Format

1. Optional RS485 and KYZ Pulse Output through backplate
2. Optional RJ45 Ethernet connection and KYZ Pulse Output through backplate

- Protocols: Modbus RTU, Modbus ASCII, Modbus TCP
- Com Port Baud Rate: 9600 to 57600 b/s
- Com Port Address: 001-247
- Data Format: 8 Bit, No Parity
- IQ 100 Series Transducer with RS485 Default Initial Communication Baud 9600 (see page 46)

Mechanical Parameters

- Dimensions: (H4.85 x W4.85 x D4.65) inches, (H123.2 x W123.2 x D118.1) mm
Mounts in 92mm square DIN or ANSI C39.1, 4" Round Cut-out
- Weight: 2 pounds, 0.907kg (ships in a 6"/152.4mm cube container)

KYZ/RS485 Port Specifications

RS485 Transceiver; meets or exceeds EIA/TIA-485 Standard

Type: Two-wire, half duplex
 Min. Input Impedance: 96kΩ
 Max. Output Current: ±60mA


Wh Pulse

KYZ output contacts (and infrared LED light pulses through face plate):
 (See page 56 for Kh values.)

Pulse Width: 40ms
 Full Scale Frequency: ~6Hz
 Contact type: Solid State – SPDT (NO – C – NC)
 Relay type: Solid state
 Peak switching voltage: DC ±350V
 Continuous load current: 120mA
 Peak load current: 350mA for 10ms


On resistance, max.:	35Ω
Leakage current:	1μA@350V
Isolation:	AC 3750V
Reset State:	(NC - C) Closed; (NO - C) Open
Infrared LED:	
Peak Spectral Wavelength:	940nm
Reset State:	Off

Internal Schematic:



(De-energized State)

Output timing:



* P [Watt] - not a scaled value
Kh - see page 56 for values.

Compliance

- UL Listing: USL/CNL E185559
- IEC 687 (0.5% Accuracy)
- ANSI C12.20 (0.5% Accuracy)
- ANSI (IEEE) C37.90.1 Surge Withstand
- ANSI C62.41 (Burst)
- CE Compliant
- IEC1000-4-2: ESD
- IEC1000-4-3: Radiated Immunity
- IEC1000-4-4: Fast Transient
- IEC1000-4-5: Surge Immunity

Accuracy

For 23° C, 3 Phase balanced Wye or Delta load, at 50 or 60 Hz (as per order), 5A (Class 10) nominal unit.

Parameters	Accuracy	Accuracy Input Range
Voltage L-N [V]	0.25% of reading ²	(69 to 480)V
Voltage L-L [V]	0.25% of reading	(120 to 600)V
Current Phase [A]	0.25% of reading ¹	(0.15 to 5)A
Current Neutral (Calculated) [A]	2.0% of reading ¹	(0.15 to 5)A @ (45 to 65)Hz
Active Power Total [W]	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0.5 to 1)lag/lead PF
Active Energy Total [Wh]	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0.5 to 1)lag/lead PF
Reactive Power Total [VAR]	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0 to 0.8)lag/lead PF
Reactive Energy Total [VARh]	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0 to 0.8)lag/lead PF
Apparent Power Total [VA]	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0.5 to 1)lag/lead PF
Apparent Energy Total [VAh]	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0.5 to 1)lag/lead PF
Power Factor	0.5% of reading ^{1,2}	(0.15 to 5)A@(69 to 480)V@ +/- (0.5 to 1)lag/lead PF
Frequency	+/- 0.01 Hz	(45 to 65) Hz
% of Load Bar	+/- 1 segment	(0.005 to 6)A

¹ For 2.5 element programmed units, degrade accuracy by an additional 0.5% of reading.



- For 1A (Class 2) Nominal, degrade accuracy by an additional 0.5% of reading.
- For 1A (Class 2) Nominal, the input current range for Accuracy specification is 20% of the values listed in the table.

² For unbalanced voltage inputs where at least one crosses the 150V auto-scale threshold (for example, 120V/120V/208V system), degrade accuracy by additional 0.4%.


IQ 100 Series Mechanical Installation

Introduction


The IQ 100 Series meter can be installed using a standard ANSI C39.1 (4" Round) or an IEC 92mm DIN (Square) form. In new installations, simply use existing DIN or ANSI punches. For existing panels, pull out old analog meters and replace with the IQ 100 Series meter. The various models use the same installation. See the next chapter for wiring diagrams.



Meter Back




ANSI Mounting Panel Cut-out



DIN Mounting Cut-out


- Recommended Tools for IQ 100 Series meter Installation: #2 Phillips screwdriver, small wrench and wire cutters. Transducer Installation doesn't require any tools.
- Mount the meter in a dry location, which is free from dirt and corrosive substances. The meter is designed to withstand harsh environmental conditions (see specifications in the previous chapter).

ANSI Installation Steps



1. Insert 4 threaded rods by hand into the back of the meter. Twist until secure.
2. Slide ANSI 12 Mounting Gasket onto the back of the meter with rods in place.
3. Slide the meter with Mounting Gasket into the panel.
4. Secure from back of panel with lock washer and nut on each threaded rod.
Use a small wrench to tighten. Do not overtighten. **The maximum installation torque is 0.4 Newton-Meter.**

DIN Installation Steps




1. Slide the meter with NEMA 12 Mounting Gasket into the panel (first remove ANSI studs, if in place).
2. From the back of the panel, slide 2 DIN Mounting Brackets into the grooves in the top and bottom of the meter housing and snap them into place.
3. Secure the meter to the panel with a lock washer and a #8 screw through each of the 2 mounting brackets. Tighten with a #2 Phillips screwdriver. Do not overtighten.

IQ 100 Series Transducer Installation

The IQ 100 Series Transducer model is installed using DIN Rail mounting.

Specs for DIN Rail mounting: International Standards DIN 46277-3
DIN Rail (Slotted) dimensions: 7.55mm x 35mm



DIN Rail Installation Steps:

1. Slide top groove of meter onto the DIN Rail.
2. Press gently until the meter clicks into place.

NOTE: If mounting with the DIN Rail provided,
use the Black Rubber Stoppers (also provided).


To Remove the Meter from the DIN Rail:

Pull down on the Release clip to detach the unit from
the DIN Rail.

NOTE ON DIN RAILS:

DIN Rails are commonly used as a mounting channel for most terminal blocks, control devices, circuit protection devices and PLCs. DIN Rails are made of electroplated cold rolled steel; they are also available in aluminum, PVC, stainless steel and copper.

Black Rubber Stoppers



DIN Rail Detail

IQ 100 Series Electrical Installation



Considerations When Installing Meters

- Installation of the IQ 100 Series meter must be performed only by qualified personnel who follow standard safety precautions during all procedures. Those personnel should have appropriate training and experience with high voltage devices. Appropriate safety gloves, safety glasses and protective clothing is recommended.
- During normal operation of the IQ 100 Series meter, dangerous voltages flow through many parts of the meter, including: Terminals and any connected CTs (Current Transformers) and PTs (Potential Transformers), all I/O Modules (Inputs and Outputs) and their circuits. All Primary and Secondary circuits can, at times, produce lethal voltages and currents. Avoid contact with any current-carrying surfaces.
- Do not use the meter for primary protection or in an energy-limiting capacity. The meter can only be used as secondary protection.
- Do not use the meter for applications where failure of the meter may cause harm or death.
- Do not use the meter for any application where there may be a risk of fire.
- All meter terminals should be inaccessible after installation.
- Do not apply more than the maximum voltage the meter or any attached device can withstand. Refer to meter and/or device labels and to the Specifications for all devices before applying voltages. Do not HIPOT/Dielectric test any Outputs, Inputs or Communications terminals.
- Eaton recommends the use of Shorting Blocks and Fuses for voltage leads and power supply to prevent hazardous voltage conditions or damage to CTs, if the meter needs to be removed from service. CT grounding is optional.



NOTE: IF THE EQUIPMENT IS USED IN A MANNER NOT SPECIFIED BY THE MANUFACTURER, THE PROTECTION PROVIDED BY THE EQUIPMENT MAY BE IMPAIRED.

NOTE: THERE IS NO REQUIRED PREVENTIVE MAINTENANCE OR INSPECTION NECESSARY FOR SAFETY. HOWEVER, ANY REPAIR OR MAINTENANCE SHOULD BE PERFORMED BY THE FACTORY.




DISCONNECT DEVICE: The following part is considered the equipment disconnect device. A SWITCH OR CIRCUIT-BREAKER SHALL BE INCLUDED IN THE END-USE EQUIPMENT OR BUILDING INSTALLATION. THE SWITCH SHALL BE IN CLOSE PROXIMITY TO THE EQUIPMENT AND WITHIN EASY REACH OF THE OPERATOR. THE SWITCH SHALL BE MARKED AS THE DISCONNECTING DEVICE FOR THE EQUIPMENT.

CT Leads Terminated to Meter

The IQ 100 Series meter is designed to have Current inputs wired in one of three ways. The diagram below shows the most typical connection where CT Leads are terminated to the meter at the current gills. This connection uses nickel-plated brass studs (current gills) with screws at each end. This connection allows the CT wires to be terminated using either an "O" or a "U" lug. Tighten the screws with a #2 Phillips screwdriver. The maximum installation torque is 1 Newton-Meter.

Other current connections are shown in the figures on the next two pages. Voltage and RS485 connections are shown on page 27.




CT Leads Terminated to Meter, #8 Screw for Lug Connection

Wiring Diagrams are shown beginning on page 28.
Communications Connections are detailed in the next chapter.

CT Leads Pass Through (No Meter Termination)


The second method allows the CT wires to pass through the CT inputs without terminating at the meter. In this case, remove the current gills and place the CT wire directly through the CT opening. The opening will accommodate up to 0.177" / 4.5mm maximum diameter CT wire.



Pass Through Wire Electrical Connection

Quick Connect Crimp CT Terminations


For quick termination or for portable applications, a quick connect Crimp CT connection can be used.



Quick Connect Electrical Connection

Voltage and Power Supply Connections

Voltage Inputs are connected to the back of the unit via optional wire connectors. The connectors accomodate up to AWG#12 / 2.5mm wire.



Ground Connections

The meter's Ground Terminals should be connected directly to the installation's protective earth ground. Use 2.5mm wire for this connection.

Voltage Fuses

Eaton recommends the use of fuses on each of the sense voltages and on the control power, even though the wiring diagrams in this chapter do not show them.

- Use a 0.1 Amp fuse on each voltage input.
- Use a 3 Amp fuse on the power supply.


Electrical Connection Diagrams

Choose the diagram that best suits your application. Be sure to maintain the CT polarity when wiring.


1. 3 Phase, 4 Wire System Wye with Direct Voltage, 3 Element
 - a. Example of Dual Phase Hookup
 - b. Example of Single Phase Hookup
2. 3 Phase, 4 Wire System Wye with Direct Voltage, 2.5 Element
4. 3 Phase, 4 Wire Wye with PTs, 2.5 Element
6. 3 Phase, 3 Wire Delta with 2 PTs
8. Current Only Measurement (Three Phase)
10. Current Only Measurement (Single Phase)


3. 3 Phase, 4 Wire Wye with PTs, 3 Element
5. 3 Phase, 3 Wire Delta with Direct Voltage
7. 3 Phase, 3 Wire Delta with 3 PTs
9. Current Only Measurement (Dual Phase)

1. Service: WYE, 4 Wire with No PTs, 3 CTs




1a. Example of Dual Phase Hookup




1b. Example of Single Phase Hookup

2. Service: 2.5 Element WYE, 4-Wire with No PTs, 3 CTs




Select: "2.5 EL WYE" (2.5 Element Wye) in Meter
Programming setup.

3. Service: WYE, 4-Wire with 3 PTs, 3 CTs




Select: "3 EL WYE" (3 Element Wye) in Meter
Programming setup.

4. Service: 2.5 Element WYE, 4-Wire with 2 PTs, 3 CTs




Select: "2.5 EL WYE" (2.5 Element Wye) in Meter Programming setup.


5. Service: Delta, 3-Wire with No PTs, 2 CTs



Select: "2 Ct dEL" (2 CT Delta) in Meter
Programming setup.


6. Service: Delta, 3-Wire with 2 PTs, 2 CTs



7. Service: Delta, 3-Wire with 2 PTs, 3 CTs


Select: "2 Ct dEL" (2 CT Delta) in Meter
Programming setup.

8. Service: Current Only Measurement (Three Phase)



Select: "3 EL WYE" (3 Element Wye) in Meter
Programming setup.


- * Even if the meter is used for only Amp readings, the unit requires a Voltage reference. Please make sure that the voltage input is attached to the meter. AC Control Power can be used to provide the Reference Signal.

9. Service: Current Only Measurement (Dual Phase)

Select: "3 EL WYE" (3 Element Wye) in Meter
Programming setup.

- * Even if the meter is used for only amp readings, the unit requires a Voltage reference. Please make sure that the voltage input is attached to the meter. AC Control Power can be used to provide the Reference Signal.

10. Service: Current Only Measurement (Single Phase)



Select: "3 EL WYE" (3 Element Wye) in Meter
Programming setup.


- * Even if the meter is used for only amp readings, the unit requires a Voltage reference. Please make sure that the voltage input is attached to the meter. AC Control Power can be used to provide the Reference Signal.

IQ 100 Series Communication Installation

RS485 / KYZ Output (Communication Port Option)


The IQ 100 Series meter provides an optional combined RS485/KYZ Pulse Output communication port, speaking Modbus ASCII or Modbus RTU.

- The IQ 100 Series meter's RS485 connection uses standard 2-wire, Half Duplex architecture. The RS485/KYZ Pulse Output connector is located on the terminal section of the meter. A connection can easily be made to a Master Device or to other Slave devices.
- Care should be taken to connect + to + and - to - connections.
- See page 56 for the KYZ Output specifications and Pulse constants.



- RS485 allows you to connect one or multiple IQ 100 Series meters to a PC or other device, at either a local or remote site. All RS485 connections are viable for up to 4000 feet (1219.20 meters).


The figure below shows a 2-wire RS485 connection in detail.




For All RS485 Connections:

- Use a shielded twisted pair cable 22 AWG (0.33 mm^2) or thicker, and ground the shield, preferably at one location only.
- Establish point-to-point configurations for each device on a RS485 bus: connect (+) terminals to (+) terminals; connect (-) terminals to (-) terminals.
- You may connect up to 31 meters on a single bus using RS485. Before assembling the bus, each meter must have a unique address.
- Protect cables from sources of electrical noise.
- Avoid both "Star" and "Tee" connections (see figure on the next page).
- **No more than two cables** should be connected **at any one point** on an RS485 network, whether the connections are for devices, converters, or terminal strips.
- Include all segments when calculating the total cable length of a network. If you are **not** using an RS485 repeater, the maximum length for cable connecting all devices is 4000 feet (1219.20 meters).
- Connect shield to RS485 Master and individual devices as shown in the figure below. You may also connect the shield to earth-ground at one point.
- **Termination Resistors (R_T)** may be needed on both ends for longer length transmission lines. However, since the meter has some level of termination internally, Termination Resistors may not be needed. When they are used, the value of the Termination Resistors is determined by the electrical parameters of the cable.

The figure below shows a representation of an RS485 Daisy Chain connection.





Incorrect Topologies

IQ 100 Series Transducer Communication Information

The IQ 100 Series Transducer model does not include a display or buttons on the front of the meter. Programming and communication utilize either the RS485 connection or the optional RJ45 connection on the back of the meter. Once a connection is established, Eaton Meter Configuration Software can be used to program the meter and communicate to IQ 100 Series slave devices. Refer to the next chapter for instructions on programming the meter.

Meter Connection

To provide power to the meter, attach an Aux cable to GND, L(+) and N(-). Refer to page 27.

Configuring the Ethernet Connection (RJ45 Port Option)

The RJ45 port option gives the IQ 100/100T Series meter a wired (RJ45) Ethernet connection speaking Modbus TCP, allowing it to communicate on a Local Area Network (LAN). The meter is easily configured through a host PC using a Telnet connection. Once configured, you can access the meter directly through any computer on your LAN.

This section outlines the procedures for setting up the parameters for Ethernet communication.

Setting up the Host PC to Communicate with the IQ100 Series meter

- Consult with your Network Administrator before performing these steps since some of the functions may be restricted to Administrator privileges.
- The Host PC could have multiple Ethernet Adapters (Network Cards) installed. Identify and configure the one that will be used for accessing the meter.
- The PC's Ethernet Adapter must be set up for point-to-point communication when configuring the RJ45 port option. The Factory default IP parameters programmed into the RJ45 port are:

IP Address: 10.0.0.1

Subnet Mask: 255.255.255.0


See following sections for additional parameters.

Configuring the Host PC's Ethernet Adapter Using Windows XP[©]


The following example shows the PC configuration settings that let you access the IQ 100 Series meter configured with default parameters. Use the same procedure when the settings differ from the default settings.

1. From the Start Menu, select Control Panel>Network Connections. You will see the window shown on the right.
2. Right click on the Local Area Network Connection you will use to connect to the meter and select Properties from the drop-down menu. You will see the window shown on the next page.





3. Select Internet Protocol [TCP/IP] and click the Properties button. You will see the window shown below.



4. Click the Use the Following IP Address radio button and enter these parameters:

IP Address: 10.0.0.2
Subnet Mask: 255.255.255.0

5. Click the OK button. You have completed the setup procedure.

Setting up the Ethernet Card in the IQ 100 Series meter

Below are the Factory Default settings for the IQ 100 Series meter's Ethernet card. These are programmed into the meter before it is shipped from the factory. Parameters in group 1 may need to be altered to satisfy the local Ethernet configuration requirements. Other parameters (2, 3, 4) should not be altered.

1) Network/IP Settings:
IP Address 10.0.0.1
Default Gateway --- not set ---
Netmask 255.255.255.0
2) Serial & Mode Settings:
Protocol Modbus/RTU,Slave(s) attached
Serial Interface 57600,8,N,1,RS232
3) Modem/Configurable Pin Settings:
CP1.....Not Used
CP2.....Not Used
CP3.....Not Used
4) Advanced Modbus Protocol settings:
Slave Addr/Unit Id Source .. Modbus/TCP header
Modbus Serial Broadcasts ... Disabled (Id=0 auto-mapped to 1)
MB/TCP Exception Codes Yes (return 00AH and 00BH)
Char, Message Timeout 00050msec, 05000msec

- The Ethernet card in the IQ 100 Series meter can be locally or remotely configured using a Telnet connection over the network.
- The configuration parameters can be changed at any time and are retained when the meter is not powered up. After the configuration has been changed and saved, the Ethernet card performs a Reset.
- Only one person at a time should be logged into the network port used for setting up the meter. This eliminates the possibility of several people trying to configure the Ethernet interface simultaneously.
- It is possible to reset the Ethernet card to its default values. See the procedure on the next page.

Configuring the IQ 100 Series Meter's Ethernet Connection using Windows XP[©] on the Host Computer

Establish a Telnet connection on port 9999. Follow these steps:

1. From the Windows Start menu, click Run and type 'cmd'.
2. Click the OK button to bring up the Windows' Command Prompt window.
3. In the Command Prompt window, type: "telnet 10.0.0.1 9999" and press the Enter key.
NOTE: Make sure there is a space between the IP address and 9999.

When the Telnet connection is established you will see a message similar to the example shown below.

```
Serial Number 5415404 MAC Address 00:20:4A:54:3C:2C
Software Version V01.2 (000719)
Press Enter to go into Setup Mode
```

4. To proceed to Setup Mode press Enter again. You will see a screen similar to the one shown below.

```
1) Network/IP Settings:
IP Address ..... 10.0.0.1
Default Gateway ..... --- not set ---
Netmask ..... 255.255.255.0
2) Serial & Mode Settings:
Protocol ..... Modbus/RTU,Slave(s) attached
Serial Interface ..... 57600,8,N,1,RS232,CH1
3) Modem/Configurable Pin Settings:
CP1.....Not Used
CP2.....Not Used
CP3.....Not Used
4) Advanced Modbus Protocol settings:
Slave Addr/Unit Id Source .. Modbus/TCP header
Modbus Serial Broadcasts ... Disabled (Id=0 auto-mapped to 1)
MB/TCP Exception Codes .... Yes (return 00AH and 00BH)
Char. Message Timeout ..... 00050msec, 05000msec
D)efault settings, S)ave, Q)uit without save
Select Command or parameter set (1..4) to change:
```

5. Change ONLY the parameters in group 1. To do so:
 - a. Type number "1."
 - b. Once group 1 is selected, the individual parameters display for editing. Either:
 - Enter a new parameter if a change is required.
 - Press Enter to proceed to the next parameter without changing the current setting.

IMPORTANT! Settings 2, 3, and 4 MUST have the default values shown above.

(Example: Setting device with static IP Address.)


```
IP Address <010> 192.<000> 168.<000> .<000> .<001>
Set Gateway IP Address <N>? Y
Gateway IP Address: <192> .<168> .<000> .<001>
Set Netmask <N for default> <Y>? Y
```

6. Continue setting up parameters as needed. When you finish your modifications, make sure to press the "S" key on the keyboard. This saves the new values and causes a Reset in the Ethernet card.
CAUTION! DO NOT PRESS 'D' as it will overwrite any changes and save the default values.

IMPORTANT! If the IP Address of the Ethernet card is lost, you can restore the factory default settings by pressing the Reset button on the card. Follow the procedure below.

Resetting the Ethernet Card

The Ethernet card's Reset button is accessed from the back of the IQ 100 Series meter. See the figure below.



Using an implement such as a ballpoint pen tip, press and hold the Reset button for 30 seconds. The Ethernet card is reset to the default settings shown on the previous page.

**IQ 100 Series (130/140/150) Meter
Communication Installations**

Programming the IQ 100 Series Meter Using the Front Panel


Introduction

You can use the Elements and Buttons on the IQ 100 Series meter's face to view meter readings, reset and/or configure the meter, and perform related functions. The following sections explain the Elements and Buttons and detail their use.

Understanding Meter Face Elements

The meter face features the following elements:


- **Reading Type Indicator:**
Indicates type of reading
- **Parameter Designator:**
Indicates reading displayed
- **Watt-Hour Test Pulse:**
Energy pulse output to test accuracy
- **Scaling Factor:**
Kilo or Mega multiplier of displayed readings
- **% of Load Bar:**
Graphic display of Amps as % of the load



Understanding Meter Face Buttons

The meter face has Menu, Enter and Right buttons, which allow you to perform the following functions:

- View meter information
- Enter display modes
- Configure parameters (may be Password protected)
- Perform resets (may be Password protected)
- Perform LED checks
- Change settings
- View parameter values
- Scroll parameter values
- View Limit states



Using the Front Panel

You can access the following modes using the meter's front panel buttons:

- Operating mode (Default mode)
- Reset mode
- Configuration mode

Use the Menu, Enter, Down and Right buttons to navigate through each mode and its related screens.

NOTES:

- Appendix A contains the complete Navigation map for the front panel display modes and their screens.
- The meter can also be configured using software (with optional communication); see the next chapter for instructions.

Understanding Startup and Default Displays

Upon Power Up, the meter displays a sequence of screens:

- Lamp Test screen where all LEDs are lit
- Lamp Test screen where all digits are lit
- Firmware screen showing build number
- Error screen (if an error exists)

After startup, if auto-scrolling is enabled, the meter scrolls the parameter readings on the right side of the front panel. The Kilo or Mega LED lights, showing the scale for the Wh, VARh and VAh readings. The figure below shows an example of a Wh reading.




The meter continues to provide scrolling readings until one of the buttons on the front panel is pressed, causing the meter to enter one of the other modes.

Using the Main Menu

1. Press the Menu button. The Main Menu screen appears.

- The Reset mode (rSt) appears in the A window. Use the Down button to scroll, causing the Configuration (CFG) and Operating (OPr) modes to move to the A window.
- The mode that is currently flashing in the A window is the “Active” mode, which means it is the mode that can be configured.



For example: Press Down Once- CFG moves to A window. Press Down Once - OPr moves to A window.

2. Press the Enter button from the Main Menu to view the parameters screen for the mode that is currently active.

Using Reset Mode

Reset mode resets **all** of the Max and Min values in the meter.

NOTE: With the communication options, you can reset both the Max/Min values and the energy accumulators. If you do not have a communication option, you cannot reset the energy accumulator fields.



Press the Enter button while rSt is in the A window. The Reset All? No screen appears.

- If you press the Enter button again, the Main Menu appears, with the next mode in the A window. (The Down button does not affect this screen.)
- If you press the Right button, the Reset All? YES screen appears. Press Enter to reset the meter’s Max and Min values.

CAUTION! Reset All? YES resets **all** Max and Min values. Only press Enter if this is what you want to do.

NOTE: If Password protection is enabled for Reset, you must enter the four digit Password before you can reset the meter. (See page 66 for information on Password Protection.)

To enter a password, follow the instructions on the next page.



Once you have performed a reset, the screen displays “rSt All donE” and then resumes auto-scrolling parameters.


Entering a Password

If Password protection has been enabled in the software for reset and/or configuration (see page 66 for information), a screen appears requesting a password when you try to reset the meter and/or configure settings through the front panel.

- PASS appears in the A window and 4 dashes appear in the B window. The leftmost dash is flashing.


1. Press the Down button to scroll numbers from 0 to 9 for the flashing dash. When the correct number appears for that dash, use the Right button to move to the next dash.

Example: The left screen, below, shows four dashes. The right screen shows the display after the first two digits of the password have been entered.



2. When all 4 digits of the password have been selected, press the Enter button.

- If you are in Reset mode and the correct password has been entered, "rSt All donE" appears and the screen resumes auto-scrolling parameters.
- If you are in Configuration mode and the correct password has been entered, the display returns to the screen that required a password.
- If an incorrect password has been entered, "PASS ---- FAIL" appears, and:
 - The previous screen is redisplayed, if you are in Reset Mode.
 - The previous Operating Mode screen is redisplayed, if you are in Configuration Mode.





Using Configuration Mode

Configuration Mode follows Reset: Energy in the Main Menu.

To access Configuration mode:

1. Press the Menu button while the meter is auto-scrolling parameters.
2. Press the Down button until the Configuration Mode option (CFG) is in the A window.
3. Press the Enter button. The Configuration Parameters screen appears.
4. Press the Down button to scroll through the configuration parameters: Scroll (SCrL), CT, PT, Connection (Cnct) and Port. The parameter currently 'Active,' i.e., configurable, flashes in the A window.
5. Press the Enter button to access the Setting screen for the currently active parameter.




NOTE: You can use the Enter button to scroll through all of the Configuration parameters and their Setting screens, in order.



Press Enter when CFG is in A window -

Parameter screen appears - Press Down-

6. The parameter screen appears, showing the current settings. To change the settings:
 - Use either the Down button or the Right button to select an option.
 - To enter a number value, use the Down button to select the number value for a digit and the Right button to move to the next digit.
 NOTE: When you try to change the current setting and Password Protection is enabled for the meter, the Password screen appears. See the previous page for instructions on entering a password.
7. Once you have entered the new setting, press the Menu button twice.
8. The Store ALL YES screen appears. You can either:
 - Press the Enter button to save the new setting.
 - Press the Right button to access the Store ALL no screen; then press the Enter button to cancel the Save.
9. If you have saved the settings, the Store ALL done screen appears and the meter is reset.



Press the Enter button to save the settings
Press the Right button for Stor All no screen

Press the Enter button to
Cancel the save

The settings have been saved

Configuring the Scroll Feature


When in Auto Scroll mode, the meter performs a scrolling display, showing each parameter for 7 seconds, with a 1 second pause between parameters. The parameters the meter displays are determined by the following conditions:

- They have been selected through software (refer to the next chapter for instructions).
- Their availability for the meter model (IQ130/140 or 150) may be restricted.

To enable or disable auto-scrolling:


1. Press the Enter button when SCrl is in the A window.

The Scroll YES screen appears.



2. Press either the Right or Down button if you want to access the Scroll no screen.

To return to the Scroll YES screen, press either button.



3. Press the Enter button on either the Scroll YES screen (to enable auto-scrolling) or the Scroll no screen (to disable auto-scrolling).

The CT- n screen appears (this is the next Configuration mode parameter).

NOTE:

- To exit the screen without changing scrolling options, press the Menu button.
- To return to the Main Menu screen, press the Menu button twice.
- To return to the scrolling (or non-scrolling) parameters display, press the Menu button three times.

Configuring CT Setting

The CT Setting has three parts: Ct-n (numerator), Ct-d (denominator), and Ct-S (scaling).

1. Press the Enter button when Ct is in the A window.

The Ct-n screen appears. You can either:

- Change the value for the CT numerator.
- Access one of the other CT screens by pressing the Enter button: press Enter once to access the Ct-d screen, twice to access the Ct-S screen.

NOTE: The Ct-d screen is preset to a 5 Amp or 1 Amp value at the factory and cannot be changed.

- a. To change the value for the CT numerator, from the Ct-n screen:

- Use the Down button to select the number value for a digit.
- Use the Right button to move to the next digit.

- b. To change the value for CT scaling, from the Ct-S screen:

Use the Right button or the Down button to choose the scaling you want. The Ct-S setting can be 1, 10, or 100.

NOTE: If you are prompted to enter a password, refer to the instructions earlier in the chapter.

2. When the new setting is entered, press the Menu button twice.


3. The Store ALL YES screen appears. Press Enter to save the new CT setting.

Example CT Settings:

200/5 Amps:	Set the Ct-n value for 200 and the Ct-S value for 1.
800/5 Amps:	Set the Ct-n value for 800 and the Ct-S value for 1.
2,000/5 Amps:	Set the Ct-n value for 2000 and the Ct-S value for 1.
10,000/5 Amps:	Set the Ct-n value for 1000 and the Ct-S value for 10.

NOTES:

- The value for Amps is a product of the Ct-n value and the Ct-S value.
- Ct-n and Ct-S are dictated by primary current; Ct-d is secondary current.



Press Enter

Use buttons to set Ct-n value The Ct-d can't be changed Use buttons to select scaling

Configuring PT Setting

The PT Setting has three parts: Pt-n (numerator), Pt-d (denominator), and Pt-S (scaling).

1. Press the Enter button when Pt is in the A window.

The PT-n screen appears. You can either:

- Change the value for the PT numerator.
- Access one of the other PT screens by pressing the Enter button: press Enter once to access the Pt-d screen, twice to access the Pt-S screen.

- a. To change the value for the PT numerator or denominator, from the Pt-n or Pt-d screen:

- Use the Down button to select the number value for a digit.
- Use the Right button to move to the next digit.

- b. To change the value for the PT scaling, from the Pt-S screen:

Use the Right button or the Down button to choose the scaling you want. The Pt-S setting can be 1, 10, 100, or 1000.

NOTE: If you are prompted to enter a password, refer to the instructions earlier in this chapter.

2. When the new setting is entered, press the Menu button twice.

3. The STOR ALL YES screen appears. Press Enter to save the new PT setting.

Example Settings:

277/277 Volts:

Pt-n value is 277, Pt-d value is 277, Pt-S value is 1.

14,400/120 Volts:

Pt-n value is 1440, Pt-d value is 120, Pt-S value is 10.

138,000/69 Volts:

Pt-n value is 1380, Pt-d value is 69, Pt-S value is 100.


345,000/115 Volts:

Pt-n value is 3450, Pt-d value is 115, Pt-S value is 100.


345,000/69 Volts:

Pt-n value is 345, Pt-d value is 69, Pt-S value is 1000.


NOTE: Pt-n and Pt-S are dictated by primary voltage; Pt-d is secondary voltage.



Use buttons to set Pt-n value



Use buttons to set Pt-d value



Use buttons to select scaling

Configuring Connection Setting

1. Press the Enter button when Cnct is in the A window. The Cnct screen appears.

2. Press the Right button or Down button to select a configuration.


The choices are:

- 3 Element Wye (3 EL WYE)
- 2.5 Element Wye (2.5EL WYE)
- 2 CT Delta (2 Ct dEL)

NOTE: If you are prompted to enter a password, refer to the instructions earlier in this chapter.

3. When you have made your selection, press the Menu button twice.

4. The STOR ALL YES screen appears. Press Enter to save the setting.



□

Configuring Communication Port Setting

Port configuration consists of : Address (a three digit number), Baud Rate (9600; 19200; 38400; or 57600), and Protocol (Modbus RTU or Modbus ASCII).

1. Press the Enter button when POrt is in the A window.

The Adr (address) screen appears. You can either:

- Enter the address.
- Access one of the other Port screens by pressing the Enter button: press Enter once to access the bAUd screen (Baud Rate); press Enter twice to access the Prot screen (Protocol).

a. To enter the Address, from the Adr screen:

- Use the Down button to select the number value for a digit.
- Use the Right button to move to the next digit.

b. To select the Baud Rate, from the bAUd screen:

Use the Right button or the Down button to select the setting you want.


c. To select the Protocol, from the Prot screen:

Press the Right button or the Down button to select the setting you want.

NOTE: If you are prompted to enter a password, refer to the instructions earlier in this chapter.

2. When you finish making your selections, press the Menu button twice.

3. The STOR ALL YES screen appears. Press Enter to save the settings.



Use buttons to enter Address

Use buttons to select Baud Rate

Use buttons to select Protocol

Using Operating Mode

Operating Mode is the IQ 100 Series meter's default mode, that is, the standard front panel display. After Startup, the meter automatically scrolls through the parameter screens, if scrolling is enabled. Each parameter is shown for 7 seconds, with a 1 second pause between parameters. Scrolling is suspended for 3 minutes after any button is pressed.

1. Press the Down button to scroll all the parameters in Operating Mode. The currently "Active," i.e., displayed, parameter has the Indicator light next to it, on the right face of the meter.
2. Press the Right button to view additional readings for that parameter. The table below shows possible readings for Operating Mode. Sheet 2 in *Appendix A* shows the Operating Mode Navigation map.
NOTE: Readings or groups of readings are skipped if not applicable to the meter type or hookup, or if they are disabled in the programmable settings.

Operating Mode Parameter Readings

POSSIBLE READINGS


VOLTS L-N	VOLTS_LN	VOLTS_LN_MAX	VOLTS_LN_MIN	
VOLTS L-L	VOLTS_LL	VOLTS_LL_MAX	VOLTS_LL_MIN	
AMPS	AMPS	AMPS_NEUTRAL	AMPS_MAX	AMPS_MIN
W/VAR/PF	W_VAR_PF	W_VAR_PF_MAX_POS	W_VAR_PF_MIN_POS	W_VAR_PF_MIN_NEG
VA/Hz	VA_FREQ	VA_FREQ_MAX	VA_FREQ_MIN	
Wh	KWH_REC	KWH_DEL	KWH_NET	KWH_TOT
VARh	KVARH_POS	KVARH_NEG	KVARH_NET	KVARH_TOT
VAh	KVAH			

Understanding the % of Load Bar

The 10-segment LED bar graph at the bottom left of the IQ 100 Series front panel provides a graphic representation of Amps. The segments light according to the load, as shown in the table below. When the Load is over 120% of full load, all segments flash "On" (1.5 secs) and "Off" (0.5 secs).

% of Load Segment Table



Segments	Load \geq % Full Load
none	no load
1	1 %
1-2	15 %
1-3	30 %
1-4	45 %
1-5	60 %
1-6	72 %
1-7	84 %
1-8	96 %
1-9	108 %
1-10	120 %
All Blink	> 120 %



Performing Watt-Hour Accuracy Testing (Verification)

To be certified for revenue metering, power providers and utility companies must verify that the billing energy meter performs to the stated accuracy. To confirm the meter's performance and calibration, power providers use field test standards to ensure that the unit's energy measurements are correct. Since the IQ 100 Series meter is a traceable revenue meter, it contains a utility grade test pulse that can be used to gate an accuracy standard. This is an essential feature required of all billing grade meters.

- Refer to the figure below for an example of how this process works.
- Refer to the table below for the Wh/Pulse constants for accuracy testing.



Using the Watt-Hour Test Pulse

Infrared & KYZ Pulse Constants for Accuracy Testing - Kh Watt-hour per pulse

Input Voltage Level	Class 10 Models	Class 2 Models
Below 150V	0.2505759630	0.0501151926
Above 150V	1.0023038521	0.2004607704

NOTES:

- Minimum pulse width is 40 milliseconds.
- Refer to the Pulse specifications in the Overview and Specifications chapter.

Programming the IQ 100 Series Meter Using Software

Overview

The IQ 100 Series meter can be configured using either the meter's faceplate buttons (Menu, Enter, Down and Right) or Eaton Meter Configuration software. To connect to the meter for software configuration, use the RS485 port, if equipped, on the back panel of the meter, or the RJ45 port if the meter has the Ethernet card option.

The IQ 100 Series Transducer must be configured with the Eaton Meter Configuration software, using either the RS485 port or the optional RJ45 port, since it does not have a front panel.

This chapter contains instructions for programming the meter and Transducer using software.



Connecting to the IQ 100 Series Meter/Transducer

1. Open Eaton Meter Configuration software.

2. Click the Connect icon on the Title bar or Connection > Quick Connect.


3. If you are connecting to the meter through your PC:

- Make sure the Serial Port radio button is selected.
- Enter Device Address (1-247).
- Select Baud Rate from the pull-down menu.
- Select the port you are using from the pull-down menu. The Available Ports/All Ports radio buttons determine which port selections the menu displays.
- Select Modbus RTU from the Protocol pull-down menu.
- Select Flow Control: None or Hardware.
- Select Echo Mode: No Echo or Static Echo.



If you are connecting to the meter through the Power Xpert® Gateway or through the RJ45 port option:

- Make sure the Network radio button is selected.
- Enter Device Address (1-247).
- Enter the Gateway or the meter's Ethernet card IP Address.
- Enter Network Port (502 for Modbus).
- Protocol defaults to Modbus TCP.




4. Click the Connect button. You will see the Device Status screen, shown below on the right.

NOTE for IQ 100 Series Transducer:

When the Transducer is powered up, for 10 seconds you can connect to the meter using the Factory Initial Default Settings (even if the Device Profile has been changed). After 10 seconds, the Device Profile reverts to the actual Device Profile in use.

Factory Initial Default Settings

Baud Rate: 9600
Port: COM1
Protocol: Modbus RTU




Accessing the IQ 100 Series Device Profile

1. Click the Profile icon in the Title Bar.



2. You will see the IQ 100 Device Profile screen. The tabs at the top of the screen allow you to navigate between Settings screens. The Buttons at the bottom of the screen allow you to perform tasks, for example, updating the Device Profile. See the example screen below.



3. To select a setting, click on its tab at the top of the screen. This causes the Settings screen to be displayed. See the following sections for instructions on configuring meter settings.

Performing Device Profile Tasks

You can perform the following tasks using the Device Profile screen buttons.


- Update: Click to send the current settings to the meter.

NOTE: You must click the Update Device button after making changes in the Settings screens, if you want to update the connected meter's settings.


- Cancel: Click to leave the Device Profile Editor screen without saving any changes.

- Load: Click to load a previously saved Device Profile settings file. You will see the Load Programmable Settings window, shown on the right.

Select the saved Device Profile you want and click Open. The settings from that file now appear in the Settings screens; for example, the CT and PT Ratios will be those from the saved Device Profile, rather than from the currently connected meter.



- Save: Click to save the Device Profile settings to a file. You will see the Save Programmable Settings window, shown on the right. Give a name to the Device Profile file and click Save.



- Report: Click to open a Notepad window containing the Device Profile settings in a text file. See the example window, shown on the right.

- Print the text file by selecting File>Print from the Notepad Title Bar.
- Save the text file by selecting File>Save from the Notepad Title Bar.

NOTE: When you click Report, you will be given the choice of viewing the Device Profile report or printing the report without viewing it on the screen.

```

2010/09/09 3:50:10 AM          Eaton Meter configuration software 1.0.0          Page 1/2
Device model: IQ 340
Device designation:
Serial number: 000137
Report Type: 4
Firmware: 0047
MLD Version: 15
Configuration: 60
COMMUNICATION SETTINGS
  COM1 (Serial)
    Baud Rate: 9600
    Address: 1
    Protocol: Modbus RTU
    Read Rate: 57600
    Response: 5bytes/line
CT SETTINGS
  Number of CTs: 2000
  Divisor for CTs: 1
  PT SETTINGS
    Number of PTs: 1440
    Divisor for PTs: 10
    Multiplier: 10
    Type of wiring: 3 element vye[ts]
POWER AND ENERGY FORMAT
  Power Scale: 1000
  Energy Offset: 0
  Decibel F-Scale: 3

```

Configuring Settings

The following sections contain detailed instructions for configuring the Device Profile settings. All of the settings are reached from tabs at the top of the Device Profile screen.

Configuring Scaling

Use this setting to configure Current Transformer and Potential Transformer ratios and to select the wiring (System Hookup).

Functional Overview of CT and PT Ratios

Current and Potential transformers are used mainly for the following reasons:

- To insulate, and as a result isolate, the meter from high-voltage circuits
- To change the primary voltage and current to standard values and sizes that the meter can measure.

The CT and PT transformers deliver fractions of the primary voltage and current to the meter. With properly set ratios and multipliers, the readings of the meter can be used to determine the energy, voltage, current, or power of the system.

This setting is the first screen displayed when you open the IQ 100 Series Device Profile. If you have been on another screen, click the Scaling tab to re-display this screen. The screen fields and acceptable entries are as follows:

CT Ratios

CT Numerator (Primary): 1 - 9999

CT Denominator (Secondary): 5 or 1 Amp

NOTE: This field is display only.

CT Multiplier (Scaling): 1, 10 or 100

Current Full Scale: Display only.

PT Ratios

PT Numerator (Primary): 1 - 9999

PT Denominator (Secondary): 40 - 600

PT Multiplier (Scaling): 1, 10, 100, or 1000

Voltage Full Scale: Display only.

System Wiring

3 Element Wye; 2.5 Element Wye; 2 CT Delta

Example Settings:

For a CT of 2000/5A, set the following CT Ratios in the entry fields:


CT Numerator (Primary) 2000

CT Denominator (Secondary) 5

CT Multiplier 1

The Current Full Scale field will read 2000.

NOTE: You can obtain the same Current Full Scale by entering a CT Numerator of 200 and a CT Multiplier of 10.



For a system that has 14400V primary with a 120V secondary line to neutral (PT Ratio of 120:1), set the following PT Ratios in the entry fields:

PT Numerator (Primary) 1440

PT Denominator (Secondary) 120

PT Multiplier 10

The Voltage Full Scale field will read 14400.

Configuring Energy and Display Settings

Click the Energy and Display tab. You will see the screen shown on the right. It displays the current settings for Power and Energy format, Demand averaging (IQ140 and above), auto-scrolling and display configuration. The screen fields and acceptable entries are as follows:

Power and Energy Format

Power Scale: Unit, kilo (k), Mega (M), Auto

Energy Digits: 5, 6, 7, 8

Decimal Places: 0 - 6

Energy Scale: Unit, kilo (k), Mega (M)

Example: Shows an example of selected settings.

Power Direction: View as Load or View as Generator

NOTES:

- The Energy Digits, Scale and Decimal Places settings determine how the Energy values are displayed.
- If invalid values are entered, you will see the following warning message:
"Warning: Current CT, PT and Energy Settings may cause invalid energy accumulator values."
Once you correct the values and click Recalculate this message goes away.



Demand Averaging (IQ140/150 only)

Average Method: Fixed or Sliding

Interval: 5, 15, 30 or 60 Minutes

Subinterval: 1, 2, 3 or 4

NOTE: Fixed Average cannot have a subinterval.

Auto Scroll Display

Clicking the checkbox turns auto-scrolling On and Off. Auto-scrolling controls the display of selected parameters on the meter's faceplate.

Display Configuration

Check the boxes of the Readings you want displayed on the faceplate of the meter. You must select at least one reading.

NOTE: This setting can be ignored for the IQ100 Series transducer, since it doesn't have a display.

Configuring Communication Settings

Use this setting to configure communication settings for the meter's RS485 Port.

NOTES:


- The settings on this screen are the current settings for communication.
- Any changes may affect communication between the meter and your PC.

Click the Communication tab. You will see the screen shown on the right. The screen fields and acceptable entries are as follows:

COM 2 (RS485)

Address: 1 - 247
Protocol: Modbus RTU, Modbus ASCII or DNP 3.0
Baud Rate: 9600, 19200, 38400, 57600
Response Delay: 0 - 750 (50 msec increments)

NOTE: Response Delay is the delay the meter should use before responding to queries. If your connecting device requires a delay before receiving information, use response delay to program the time to wait before the meter starts responding to queries.




Configuring (System) Settings

Use this setting to configure meter password or assign a meter designation.

Click the Settings tab. You will see the screen shown on the right.

- To enable or disable Password protection for reset and/or configuration:
Click the checkbox next to the option. Enabling Password protection prevents unauthorized tampering with devices.
- IMPORTANT! You must set up a password before enabling Password protection. Click the Change button next to Change Password if you have not already set up a password.
- To Change the device designation: input a new designation into this field.



When you click the Change button next to Change Password in the Settings screen, you will see the message window shown on the right.

1. Type in the new password (0 - 9999).
2. Retype the password.
3. Click Change. The new password is saved and the meter restarts.
4. You can now enable the password for reset (Reset Max/Min Energy Settings) or configuration (Device Profile) by clicking the checkbox next to the option.



When a user attempts to make a change that is under Password protection, the Eaton Meter Configuration software opens a message window asking for the password. If the correct password is not entered, the change does not take place.

Polling the IQ 100 Series Meter

The Real Time Poll features of Eaton Meter Configuration software are used to continuously view instantaneous values within an IQ 100 Series meter. The software provides tabular views of metered values, circuit measurements, interval data, and pulse data.

The Real Time Poll features are divided into three groups, accessed by clicking Real-Time Poll in the Title Bar:

- Real Time Readings
- Revenue, Energy and Demand Readings
- Power Quality



When you click Real Time Readings; Revenue, Energy and Demand Readings; and Power Quality and Alarms, you will see a sub-menu that allows you to select individual polling screens.

NOTE: Clicking the Polling icon on the Title Bar is the same as selecting Instantaneous Polling from the Real-Time Poll>Real Time Readings menu; clicking the Phasors icon on the Title Bar is the same as selecting Phasors from the Real-Time Poll>Power Quality and Alarms menu.

Instantaneous Polling

Click Real-Time Poll>Real Time Readings>Instantaneous Polling. You will see the screen shown below.

Voltage and Current			
Voltage			
A-N	Volts 0.00	Max Volts 14.27k	Min Volts 0.00
B-N	0.00	14.28k	0.00
C-N	0.00	14.28k	0.00
A-B	0.00	28.55k	0.00
B-C	0.00	28.56k	0.00
C-A	0.00	0.31k	0.00
Current			
A	Amps 0.00	Max Demand 0.00	Min Demand 0.00
B	0.00	0.00	0.00
C	0.00	0.00	0.00
N	0.00		
Frequency			
	Hertz 0.00	Max 60.04	Min 0.00
<input checked="" type="checkbox"/> Polling <input type="button" value="OK"/> <input type="button" value="Print"/> <input type="button" value="Help"/>			

- Click Print to print a copy of the screen.
- Click Help to view instructions for this screen.
- Click OK to return to the main screen.

Poll Power and Demand

Click Real-Time Poll > Revenue, Energy and Demand Readings > Power and Demand. You will see the screen shown below.


Power and Energy

Power		Max Demand	Min Demand
Apparent(VA)	17.36M		
Real(+ Watts)	17.35M		
Real(- Watts)			
Reactive(+ VARs)	0.49M		
Reactive(- VARs)			
+ PF	1.000		
- PF			
Demand Window		Fixed Window	
Integration Period		15 minutes	
Energy			
	Received	Delivered	Net
Watt-hr			
VAR-hr			
VA-hr			
Polling ..		OK	Print
			Help

- Click Print to print a copy of the screen.
- Click Help to view instructions for this screen.
- Click OK to return to the main screen.

Poll Phasors

Click Real Time Poll>Power Quality and Alarms>Phasors. You will see the screen shown below.



The Phasors screen displays the Phase relationships of the currently connected meter. If you have an auxiliary voltage reading (i.e. generator and bus where the VAux is the generator), the Aux box and the VAux phasor are displayed. The VAux phasor is referenced to VA phase.


To adjust the Phasor display, click Options at the bottom of the screen.

You will see the screen shown on the right.

- In the Display Angles Increasing and Phasor Rotation boxes, select either Clockwise or Counter Clockwise.
- From the pull-down menu at the bottom of the screen, select Vectors, Triangles or Vectors and Triangles to change the graphic representation of the data.


Click OK to save your selections and return to the Phasors screen.

- Click Copy to save a copy of the screen to the clipboard.
- Click Print to send a copy of the graph to a printer.
- Click Help to view instructions for this screen.
- Click OK to return to the main screen.



Using the IQ 100 Series Tools Menu

The Tools Menu allows you to access specific functions for the IQ 100 Series Meter. Click Tools from the Title Bar to display the Tools Menu.




Accessing the Device Profile Screen

Click the first option, Edit Current Device Profile, to open the Device Profile screen. This menu option performs the same function as clicking the Profile icon in the Title Bar.

Reset Device Information

Click this option to reset either Max/Min values (IQ 130, IQ 140, and IQ 150 meters) and/or Energy Accumulators (IQ 150 only). You will see the screen shown on the right. Click the checkbox next to the item(s) you want to reset.



Retrieve Device Status

Click this option to see the Device status screen for the meter. this is the same screen that displays when you first connect to the meter.


Flash Update Firmware

Click this option to upgrade the meter's firmware. You will see the screen on the right.

Click Browse to locate the flash file.

Click OK to update the firmware with the flash file. When flashing is complete, click Exit to close the screen.

NOTE: Flash updating of firmware can only be done at a Baud Rate of 57.6k.



Performing Additional Tasks with Eaton Meter Configuration Software

The following sections contain instructions for other tasks you can perform using the Eaton Meter Configuration software.

Using Connection Manager

Use Connection Manager to add or remove connection locations and/or devices at locations.

1. Click Connection > Connection Manager or click on the Connect Mgr icon. You will see the screen shown on the right.

List of Locations:

On the left side of the Connection Manager screen is a List of Locations. These are the locations of one or more meters to which you can connect. You can add a location and/or a device; edit a location and/or device; or remove a location and/or device.


- To add a location:
 - a. Click on the Add button. You will see the Connection Manager Location Editor screen. On this screen, you program the Communication settings for each new location.
 - b. Type a name for the new location.
 - c. Click Serial Port or Network.
 - d. Enter Communication settings:

Com Port: COM 1 - 99
Baud Rate: 1200 - 115200
Flow Control: None or Hardware
Data Bits: 8 (or 7)
Parity: None (Even, Odd)

- e. To add a device:
 - Click Add Serial (to add a Serial Port connected device) or Add Net (to add a Network connected device) in the Devices at Location box. You can add up to 255 devices (Serial Port and/or Network connected) at one location.

NOTES:

- All devices must have the same connection parameters: Baud, Parity and Flow Control.
- Multiple devices slow down polling.



f. To edit a device:

- Select the device from the Devices at Location box. (Scroll down to find all devices.)
- Click Edit. You will see the Connection Manager Location Device Editor screen, shown on the right.
- Use this screen to program the device properties for each device at a location.
 - If the device has a Serial Port device connection, you will see the first (top) example screen.
 - If the device has a Network device connection, you will see the second example screen.

NOTE: Click the Network or Serial button at the top of the screen to switch connection screens.



- Enter Device Properties:

Address:	1 - 247 (Unique Address)
Name:	Device Name
Description:	(Type and Number, for example)
Protocol:	Modbus RTU, ASCII, or Modbus TCP
Device Type:	IQ Meter
Comm Port:	1 or 2 (Serial Port Only)
IP Address:	100.10.10.10 (for example) (Network Only)
Port Number:	502 (Default) (Network Only)



- Click Close to save settings and return to the Connection Manager Location Editor screen.

- g. To remove a device, select the device from the Devices at Location box and click Remove.
- h. Click Close to return to the Connection Manager screen.

• To edit a location:

- a. Select a location from the List of Locations box.
- b. Click the Edit button. The Connection Manager Location Editor screen appears, displaying the current settings for the location.
- c. Make any changes to settings and/or devices at the location.
- d. Click Close to exit the screen.

• To remove a location:

- a. Select a location from the List of Locations box.
- b. Click Remove.
- c. Click Yes in the Confirmation window.

• To sort the list of locations:

- a. Select a sort method (A-Z, Z-A, Newest-Oldest or Oldest-Newest) from the pull-down menu.
- b. Click Sort By.

- To connect to a location:
 - a. Select the location you want to connect to from the List of Locations box.

NOTE: You may only connect to one location at a time. To change to a different location, you must disconnect from the current location by selecting it and clicking Disconnect.

- b. Click Connect. When the connection is made, the selected location appears in the Connected To Locations section of the screen.
- c. Click Close. The Device Status screen opens, confirming the connection. The computer Status bar at the bottom of the screen also confirms the computer's connection parameters.

NOTE: If the connection fails, a popup screen alerts you. Check that all cables are secure, that the RS232 cable is connected to the correct Com Port on the computer, and that the computer is set to use the same baud rate and protocol as the meter to which the computer is connected.

Disconnecting from an IQ 100 Series meter


To disconnect from an IQ 100 Series meter or from a location, do one of the following:

- Click on the Disconnect icon in the Title Bar.
- Select Connection > Disconnect from the Title Bar.
- From the Connection Manager screen, select the location from the Connected to Location field and click the Disconnect button.

Changing the Primary Device/Address

Use this feature to select another meter as the primary device.


1. Click Connect > Change Primary Device/Address. You will see the screen on the right.
2. Enter the address of the device you want to designate as the new Primary Device.
3. Click OK.



Merging Connection Databases


Use this feature to combine two sets of cnexcom databases.

1. Click Connection > Merge Connection Databases. You will see the screen on the right. It allows you to select the two databases to merge.
2. Click the Browse button next to each field to pick the databases. The Source cnexcom database will be merged into the Destination cnexcom database.
3. Click the Merge button to proceed with the merge; click OK to exit the screen.



Using the Options Screen

1. Click View>Options. You will see the screen shown on the right. Use this screen to access the following features:
 - Paths for Eaton Meter Configuration software files
 - Data Scan mode
 Use the tabs at the top of the screen to access these features.
2. The first Options screen is the Paths screen, shown on the right. Use this screen to view or change the paths the Eaton Meter Configuration software uses for data.
3. Click the Data Scan Mode tab to see the second screen on the right. Use this screen to select normal scan rate or to enter a custom scan rate.
4. Click:
 - Apply to apply your selection(s) and keep the Options screen open
 - Okay to apply your selection and close the Options screen
 - Cancel to close the Options screen without saving any selections that have not been applied



Using the Help Menu

The Help menu, accessed by clicking Help in the Title Bar, allows you to:

- View this manual online: click Help>this User Manual.
- View information about the Eaton Meter Configuration software, including version number: click Help>About Eaton Meter Configuration Software.

App. A: IQ 100 Series Navigation Maps

Introduction

You can configure the IQ 100 Series meter and perform related tasks using the buttons on the meter face. This appendix contains the Navigation maps for the meter's front panel displays.


Navigation Maps (Sheets 1 to 4)

The IQ 100 Series Navigation maps begin on the next page. The maps show in detail how to move from one screen to another and from one display mode to another using the buttons on the face of the meter. All display modes automatically return to Operating mode after 10 minutes with no user activity.


Navigation map titles:

- Main Menu screens (Sheet 1)
- Operating mode screens (Sheet 2)
- Reset mode screens (Sheet 3)
- Configuration mode screens (Sheet 4)


Main Menu Screens (Sheet 1)




BUTTONS	
MENU	Returns to previous menu from any screen in any mode.
ENTER	Indicates acceptance of the current screen and advances to the next one.
DOWN, RIGHT Navigation:	No digits or legends are blinking. On a menu, DOWN advances to the next menu selection, RIGHT does nothing. In a grid of screens, DOWN advances to the next row, RIGHT advances to the next column. Rows, columns and menus all navigate circularly.
Editing:	A digit or legend is blinking to indicate that it is eligible for change. When a digit is blinking, DOWN increases the digit value, RIGHT moves to the next digit. When a legend is blinking, either button advances to the next choice legend.




— button —>



Reset Mode Screens (Sheet 3)



Configuration Mode Screens (Sheet 4)



App.B: Modbus Mapping for the IQ 100 Series

Introduction

The Modbus map for the IQ 100 Series meter gives details and information about the possible readings of the meter and its programming.

Modbus Register Map Sections

The IQ 100 Series Modbus register map includes the following sections:

Fixed Data Section, Registers 1- 47, details the meter's Fixed Information.

Meter Data Section, Registers 1000 - 12031, details the meter's readings, including Primary readings, Energy Block, Demand Block (IQ 140/150 meter), Phase Angle Block, Status Block, and Minimum and Maximum readings.

Commands Section, Registers 20000 - 26011, details the meter's Resets Block, Programming Block, Other Commands Block and Encryption Block.

Programmable Settings Section, Registers 30000 - 33575, details all the setups you can program to configure your meter.

Secondary Readings Section, Registers 40001 - 40100, details the meter's Secondary readings.

Data Formats

ASCII: ASCII characters packed 2 per register in high, low order and without any termination characters.

SINT16/UINT16: 16-bit signed/unsigned integer.

SINT32/UINT32: 32-bit signed/unsigned integer spanning 2 registers. The lower-addressed register is the high order half.

FLOAT: 32-bit IEEE floating point number spanning 2 registers. The lower-addressed register is the high order half (i.e., contains the exponent).

Floating Point Values

Floating Point Values are represented in the following format:

Regis- ter	0															1																
Byte	0								1								0								1							
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Meaning	s	e	e	e	e	e	e	e	e	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	
	sign															mantissa																

The formula to interpret a Floating Point Value is: $-1^{\text{sign}} \times 2^{\text{exponent}-127} \times 1.\text{mantissa} = 0x0C4E11DB9$
 $-1^{\text{sign}} \times 2^{137-127} \times 1 \bullet 1000010001110110111001$
 $-1 \times 2^{10} \times 1.75871956$
 -1800.929

Regis- ter	0xC4E1															0x01DB9																
Byte	0xC4								0xE1								0x01D								0x0B9							
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Meaning	s	e	e	e	e	e	e	e	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	m	
	sign															mantissa																
	1	0x089 + 137															0b01100001000111011011001															

Formula Explanation:

C4E11DB9 (hex)

11000100 11100001 00011101 10111001 (binary)

The sign of the mantissa (and therefore the number) is 1, which represents a negative value.

The Exponent is 10001001 (binary) or 137 decimal.

The Exponent is a value in excess 127. So, the Exponent value is 10.

The Mantissa is 1100001000111011011001 binary.

With the implied leading 1, the Mantissa is (1).C23B72 (hex).

The Floating Point Representation is therefore $-1.75871956 \times 2^{10}$ times 10.

Decimal equivalent: -1800.929

NOTES:

- Exponent = the whole number before the decimal point.
- Mantissa = the positive fraction after the decimal point.

Important Note Concerning the IQ 100 Series Modbus Map

In depicting Modbus Registers (Addresses), the IQ 100 Series meter's Modbus map uses Holding Registers only.

Hex Representation

The representation shown in the table below is used by developers of Modbus drivers and libraries, SEL 2020/2030 programmers and Firmware Developers. The meter's Modbus map also uses this representation.

Hex	Description
0008 – 000F	Meter Serial Number

Decimal Representation

The meter's Modbus map defines Holding Registers as (4X) registers. Many popular SCADA and HMI packages and their Modbus drivers have user interfaces that require users to enter these Registers starting at 40001. So instead of entering two separate values, one for register type and one for the actual register, they have been combined into one number.

The meter's Modbus map uses a shorthand version to depict the decimal fields -i.e., not all of the digits required for entry into the SCADA package UI are shown.

For example:

You need to display the meter's serial number in your SCADA application. The meter's Modbus map shows the following information for meter serial number:

Decimal	Description
9 – 16	Meter Serial Number

In order to retrieve the meter's serial number, enter 40009 into the SCADA UI as the starting register, and 8 as the number of registers.

- In order to work with SCADA and Driver packages that use the 40001 to 49999 method for requesting holding registers, take 40000 and add the value of the register (Address) in the decimal column of the Modbus Map. Then enter the number (e.g., 4009) into the UI as the starting register.
- For SCADA and Driver packages that use the 400001 to 465536 method for requesting holding registers take 400000 and add the value of the register (Address) in the decimal column of the Modbus Map. Then enter the number (e.g., 400009) into the UI as the starting register. The drivers for these packages strip off the leading four and subtract 1 from the remaining value. This final value is used as the starting register or register to be included when building the actual modbus message.

Modbus Register Map (MM-1 to MM-16)

The IQ 100 Series Modbus register map begins on the following page.

Modbus Address		Description ¹	Format	Range ⁶	Units or Resolution	Comments	# Reg					
Hex	Decimal											
Fixed Data Section												
Identification Block												
0000 - 0007	1 - 8	Reserved			none		8					
0008 - 000F	9 - 16	Meter Serial Number	ASCII	16 char	none		8					
0010 - 0010	17 - 17	Meter Type	UINT16	bit-mapped	-----t-----	t = transducer model (1=yes, 0=no)	1					
0011 - 0012	18 - 19	Firmware Version	ASCII	4 char	none		2					
0013 - 0013	20 - 20	Map Version	UINT16	0 to 65535	none		1					
0014 - 0014	21 - 21	Meter Configuration	UINT16	bit-mapped	-----ffff	ffff = calibration frequency (50 or 60)	1					
0015 - 0015	22 - 22	ASIC Version	UINT16	0-65535	none		1					
0016 - 0026	23 - 39	Reserved					17					
0027 - 002E	40 - 47	Reserved					8					
							Block Size: 47					
Meter Data Section²												
Primary Readings Block, 6 cycles (IEEE Floating Point)												
0383 - 0384	900 - 901	Watts, 3-Ph total	FLOAT	-9999 M to +9999 M	watts		2					
0385 - 0386	902 - 903	VARs, 3-Ph total	FLOAT	-9999 M to +9999 M	VARs		2					
0387 - 0388	904 - 905	VAs, 3-Ph total	FLOAT	-9999 M to +9999 M	VAs		2					
							Block Size: 6					
Primary Readings Block, 60 cycles (IEEE Floating Point)												
03E7 - 03E8	1000 - 1001	Volts A-N	FLOAT	0 to 9999 M	volts		2					
03E9 - 03EA	1002 - 1003	Volts B-N	FLOAT	0 to 9999 M	volts		2					
03EB - 03EC	1004 - 1005	Volts C-N	FLOAT	0 to 9999 M	volts		2					
03ED - 03EE	1006 - 1007	Volts A-B	FLOAT	0 to 9999 M	volts		2					
03EF - 03F0	1008 - 1009	Volts B-C	FLOAT	0 to 9999 M	volts		2					
03F1 - 03F2	1010 - 1011	Volts C-A	FLOAT	0 to 9999 M	volts		2					
03F3 - 03F4	1012 - 1013	Amps A	FLOAT	0 to 9999 M	amps		2					
03F5 - 03F6	1014 - 1015	Amps B	FLOAT	0 to 9999 M	amps		2					
03F7 - 03F8	1016 - 1017	Amps C	FLOAT	0 to 9999 M	amps		2					
03F9 - 03FA	1018 - 1019	Watts, 3-Ph total	FLOAT	-9999 M to +9999 M	watts		2					
03FB - 03FC	1020 - 1021	VARs, 3-Ph total	FLOAT	-9999 M to +9999 M	VARs		2					
03FD - 03FE	1022 - 1023	VAs, 3-Ph total	FLOAT	-9999 M to +9999 M	VAs		2					
03FF - 0400	1024 - 1025	Power Factor, 3-Ph total	FLOAT	-1.00 to +1.00	none		2					
0401 - 0402	1026 - 1027	Frequency	FLOAT	0 to 65.00	Hz		2					

Modbus Address		Description ¹	Format	Range ⁶	Units or Resolution	Comments	# Reg
Hex	Decimal						
0403 - 0404	1028 - 1029	Neutral Current	FLOAT	0 to 9999 M	amps		2
						Block Size:	30
Primary Energy Block							
044B - 044C	1100 - 1101	W-hours, Received	SINT32	0 to 99999999 or 0 to -99999999	Wh per energy format	* Wh received & delivered always have opposite signs	2
044D - 044E	1102 - 1103	W-hours, Delivered	SINT32	0 to 99999999 or 0 to -99999999	Wh per energy format	* Wh received is positive for "view as load", delivered is positive for "view as generator"	2
044F - 0450	1104 - 1105	W-hours, Net	SINT32	-99999999 to 99999999	Wh per energy format		2
0451 - 0452	1106 - 1107	W-hours, Total	SINT32	0 to 99999999	Wh per energy format	* 5 to 8 digits	2
0453 - 0454	1108 - 1109	VAR-hours, Positive	SINT32	0 to 99999999	VARh per energy format	* decimal point implied, per energy format	2
0455 - 0456	1110 - 1111	VAR-hours, Negative	SINT32	0 to -99999999	VARh per energy format	* resolution of digit before decimal point = units, kilo, or mega, per energy format	2
0457 - 0458	1112 - 1113	VAR-hours, Net	SINT32	-99999999 to 99999999	VARh per energy format		2
0459 - 045A	1114 - 1115	VAR-hours, Total	SINT32	0 to 99999999	VARh per energy format		2
045B - 045C	1116 - 1117	VA-hours, Total	SINT32	0 to 99999999	VAh per energy format	* see note 10	2
						Block Size:	18
Primary Demand Block (IEEE Floating Point)							
07CF - 07D0	2000 - 2001	Amps A, Average	FLOAT	0 to 9999 M	amps		2
07D1 - 07D2	2002 - 2003	Amps B, Average	FLOAT	0 to 9999 M	amps		2
07D3 - 07D4	2004 - 2005	Amps C, Average	FLOAT	0 to 9999 M	amps		2
07D5 - 07D6	2006 - 2007	Positive Watts, 3-Ph, Average	FLOAT	-9999 M to +9999 M	watts		2
07D7 - 07D8	2008 - 2009	Positive VARs, 3-Ph, Average	FLOAT	-9999 M to +9999 M	VARs		2
07D9 - 07DA	2010 - 2011	Negative Watts, 3-Ph, Average	FLOAT	-9999 M to +9999 M	watts		2
07DB - 07DC	2012 - 2013	Negative VARs, 3-Ph, Average	FLOAT	-9999 M to +9999 M	VARs		2
07DD - 07DE	2014 - 2015	VAs, 3-Ph, Average	FLOAT	-9999 M to +9999 M	VAs		2
07DF - 07E0	2016 - 2017	Positive PF, 3-Ph, Average	FLOAT	-1.00 to +1.00	none		2
07E1 - 07E2	2018 - 2019	Negative PF, 3-PF, Average	FLOAT	-1.00 to +1.00	none		2
						Block Size:	20
Primary Minimum Block (IEEE Floating Point)							
0BB7 - 0BB8	3000 - 3001	Volts A-N, Minimum	FLOAT	0 to 9999 M	volts		2
0BB9 - 0BBA	3002 - 3003	Volts B-N, Minimum	FLOAT	0 to 9999 M	volts		2
0BBC - 0BBC	3004 - 3005	Volts C-N, Minimum	FLOAT	0 to 9999 M	volts		2
0BBD - 0BBE	3006 - 3007	Volts A-B, Minimum	FLOAT	0 to 9999 M	volts		2
0BBF - 0BC0	3008 - 3009	Volts B-C, Minimum	FLOAT	0 to 9999 M	volts		2

Modbus Address		Description ¹	Format	Range ⁶	Units or Resolution	Comments	# Reg
Hex	Decimal						
0BC1 - 0BC2	3010 - 3011	Volts C-A, Minimum	FLOAT	0 to 9999 M	volts		2
0BC3 - 0BC4	3012 - 3013	Amps A, Minimum Avg Demand	FLOAT	0 to 9999 M	amps		2
0BC5 - 0BC6	3014 - 3015	Amps B, Minimum Avg Demand	FLOAT	0 to 9999 M	amps		2
0BC7 - 0BC8	3016 - 3017	Amps C, Minimum Avg Demand	FLOAT	0 to 9999 M	amps		2
0BC9 - 0BCA	3018 - 3019	Positive Watts, 3-Ph, Minimum Avg Demand	FLOAT	0 to +9999 M	watts		2
0BCB - 0BCC	3020 - 3021	Positive VARs, 3-Ph, Minimum Avg Demand	FLOAT	0 to +9999 M	VARs		2
0BCD - 0BCE	3022 - 3023	Negative Watts, 3-Ph, Minimum Avg Demand	FLOAT	0 to +9999 M	watts		2
0BCF - 0BD0	3024 - 3025	Negative VARs, 3-Ph, Minimum Avg Demand	FLOAT	0 to +9999 M	VARs		2
0BD1 - 0BD2	3026 - 3027	VAs, 3-Ph, Minimum Avg Demand	FLOAT	-9999 M to +9999 M	VAs		2
0BD3 - 0BD4	3028 - 3029	Positive Power Factor, 3-Ph, Minimum Avg Demand	FLOAT	-1.00 to +1.00	none		2
0BD5 - 0BD6	3030 - 3031	Negative Power Factor, 3-Ph, Minimum Avg Demand	FLOAT	-1.00 to +1.00	none		2
0BD7 - 0BD8	3032 - 3033	Frequency, Minimum	FLOAT	0 to 65.00	Hz		2
							Block Size: 34
Primary Maximum Block (IEEE Floating Point)							
0C1B - 0C1C	3100 - 3101	Volts A-N, Maximum	FLOAT	0 to 9999 M	volts		2
0C1D - 0C1E	3102 - 3103	Volts B-N, Maximum	FLOAT	0 to 9999 M	volts		2
0C1F - 0C20	3104 - 3105	Volts C-N, Maximum	FLOAT	0 to 9999 M	volts		2
0C21 - 0C22	3106 - 3107	Volts A-B, Maximum	FLOAT	0 to 9999 M	volts		2
0C23 - 0C24	3108 - 3109	Volts B-C, Maximum	FLOAT	0 to 9999 M	volts		2
0C25 - 0C26	3110 - 3111	Volts C-A, Maximum	FLOAT	0 to 9999 M	volts		2
0C27 - 0C28	3112 - 3113	Amps A, Maximum Avg Demand	FLOAT	0 to 9999 M	amps		2
0C29 - 0C2A	3114 - 3115	Amps B, Maximum Avg Demand	FLOAT	0 to 9999 M	amps		2
0C2B - 0C2C	3116 - 3117	Amps C, Maximum Avg Demand	FLOAT	0 to 9999 M	amps		2
0C2D - 0C2E	3118 - 3119	Positive Watts, 3-Ph, Maximum Avg Demand	FLOAT	0 to +9999 M	watts		2
0C2F - 0C30	3120 - 3121	Positive VARs, 3-Ph, Maximum Avg Demand	FLOAT	0 to +9999 M	VARs		2
0C31 - 0C32	3122 - 3123	Negative Watts, 3-Ph, Maximum Avg Demand	FLOAT	0 to +9999 M	watts		2
0C33 - 0C34	3124 - 3125	Negative VARs, 3-Ph, Maximum Avg Demand	FLOAT	0 to +9999 M	VARs		2
0C35 - 0C36	3126 - 3127	VAs, 3-Ph, Maximum Avg Demand	FLOAT	-9999 M to +9999 M	VAs		2
0C37 - 0C38	3128 - 3129	Positive Power Factor, 3-Ph, Maximum Avg Demand	FLOAT	-1.00 to +1.00	none		2
0C39 - 0C3A	3130 - 3131	Negative Power Factor, 3-Ph, Maximum Avg Demand	FLOAT	-1.00 to +1.00	none		2
0C3B - 0C3C	3132 - 3133	Frequency, Maximum	FLOAT	0 to 65.00	Hz		2
							Block Size: 34
Reserved Block^{7, 13}							
0F9F - 0F9F	4000 - 4000	Reserved	UINT16	0 to 9999, or 65535	0.1%		1
0FA0 - 0FA0	4001 - 4001	Reserved	UINT16	0 to 9999, or 65535	0.1%		1
0FA1 - 0FA1	4002 - 4002	Reserved	UINT16	0 to 9999, or 65535	0.1%		1
0FA2 - 0FA2	4003 - 4003	Reserved	UINT16	0 to 9999, or 65535	0.1%		1

Modbus Address		Description ¹	Format	Range ⁶	Units or Resolution	Comments	# Reg
Hex	Decimal						
0FA3 - 0FA3	4004 - 4004	Reserved					1
0FA4 - 0FA4	4005 - 4005	Reserved					1
0FA5 - 0FA5	4006 - 4006	Reserved					1
0FA6 - 0FA6	4007 - 4007	Reserved					1
0FA7 - 0FA7	4008 - 4008	Reserved					1
0FA8 - 0FA8	4009 - 4009	Reserved					1
0FA9 - 0FA9	4010 - 4010	Reserved					1
0FAA - 0FAA	4011 - 4011	Reserved					1
0FAB - 0FAB	4012 - 4012	Reserved					1
0FAC - 0FAC	4013 - 4013	Reserved					1
0FAD - 0FAD	4014 - 4014	Reserved					1
0FAE - 0FAE	4015 - 4015	Reserved					1
0FAF - 0FAF	4016 - 4016	Reserved					1
0FB0 - 0FB0	4017 - 4017	Reserved					1
0FB1 - 0FB8	4018 - 4025	Reserved					8
0FB9 - 0FBC	4026 - 4029	Reserved					4
0FBF - 0FC4	4030 - 4037	Reserved					8
0FC5 - 0FC8	4038 - 4041	Reserved					4
							Block Size: 42
Phase Angle Block¹⁴							read-only
1003 - 1003	4100 - 4100	Phase A Current	SINT16	-1800 to +1800	0.1 degree		1
1004 - 1004	4101 - 4101	Phase B Current	SINT16	-1800 to +1800	0.1 degree		1
1005 - 1005	4102 - 4102	Phase C Current	SINT16	-1800 to +1800	0.1 degree		1
1006 - 1006	4103 - 4103	Angle, Volts A-B	SINT16	-1800 to +1800	0.1 degree		1
1007 - 1007	4104 - 4104	Angle, Volts B-C	SINT16	-1800 to +1800	0.1 degree		1
1008 - 1008	4105 - 4105	Angle, Volts C-A	SINT16	-1800 to +1800	0.1 degree		1
							Block Size: 6
Status Block							read-only
1387 - 1387	5000 - 5000	Meter Status	UINT16	bit-mapped	-- exnpch ssssssss	exnpch = EEPROM block OK flags (e=energy, x=max, n=min, p=programmable settings, c=calibration, h=header), ssssssss = state (1=Run, 2=Limp, 10=Prog Set Update via buttons, 12=Prog Set Update via COM2)	1
1388 - 1388	5001 - 5001	Reserved					1
1389 - 138A	5002 - 5003	Time Since Reset	UINT32	0 to 4294967294	4 msec	wraps around after max count	2
							Block Size: 4

Modbus Address		Description ¹	Format	Range ⁶	Units or Resolution	Comments	# Reg
Hex	Decimal						
Commands Section⁴							
Resets Block ³						write-only	
4E1F - 4E1F	20000 - 20000	Reset Max/Min Blocks	UINT16	password ⁵			1
4E20 - 4E20	20001 - 20001	Reset Energy Accumulators	UINT16	password ⁵			1
						Block Size:	2
Meter Programming Block							
55EF - 55EF	22000 - 22000	Initiate Programmable Settings Update	UINT16	password ⁵		meter enters PS update mode	1
55F0 - 55F0	22001 - 22001	Terminate Programmable Settings Update ³	UINT16	any value		meter leaves PS update mode via reset	1
55F1 - 55F1	22002 - 22002	Calculate Programmable Settings Checksum ³	UINT16			meter calculates checksum on RAM copy of PS block	1
55F2 - 55F2	22003 - 22003	Programmable Settings Checksum ³	UINT16			read/write checksum register; PS block saved in EEPROM on write ³	1
55F3 - 55F3	22004 - 22004	Write New Password ³	UINT16	0000 to 9999		write-only register; always reads zero	1
59D7 - 59D7	23000 - 23000	Initiate Meter Firmware Reprogramming	UINT16	password ⁵			1
						Block Size:	6
Other Commands Block							
61A7 - 61A7	25000 - 25000	Force Meter Restart	UINT16	password ⁵		causes a watchdog reset, always reads 0	1
						Block Size:	1
Encryption Block							
658F - 659A	26000 - 26011	Perform a Secure Operation	UINT16			encrypted command to read password or change meter type	12
						Block Size:	12
Programmable Settings Section							
Basic Setups Block							
752F - 752F	30000 - 30000	CT multiplier & denominator	UINT16	bit-mapped	ddddddddd mmmmmmmmm	write only in PS update mode high byte is denominator (1 or 5, read-only), low byte is multiplier (1, 10, or 100)	1
7530 - 7530	30001 - 30001	CT numerator	UINT16	1 to 9999	none		1
7531 - 7531	30002 - 30002	PT numerator	UINT16	1 to 9999	none		1
7532 - 7532	30003 - 30003	PT denominator	UINT16	1 to 9999	none		1

Modbus Address		Description ¹	Format	Range ⁶	Units or Resolution	Comments	# Reg
Hex	Decimal						
7533 - 7533	30004 - 30004	PT multiplier & hookup	UINT16	bit-mapped	mmmmmmmm MMMMhhhh	MMMMmmmmmmmm is PT multiplier (1, 10, 100, 1000), hhhh is hookup enumeration (0 = 3 element wye[9S], 1 = delta 2 CTs[5S], 3 = 2.5 element wye[6S])	1
7534 - 7534	30005 - 30005	Averaging Method	UINT16	bit-mapped	--iiiiii b----sss	iiiiii = interval (5,15,30,60) b = 0-block or 1-rolling sss = # subintervals (1,2,3,4)	1
7535 - 7535	30006 - 30006	Power & Energy Format	UINT16	bit-mapped	pppp--nn -eee-ddd	pppp = power scale (0-unit, 3-kilo, 6-mega, 8-auto) nn = number of energy digits (5-8 --> 0-3) eee = energy scale (0-unit, 3-kilo, 6-mega) ddd = energy digits after decimal point (0-6) See note 10.	1
7536 - 7536	30007 - 30007	Operating Mode Screen Enables	UINT16	bit-mapped	00000000 eeeeeeee	eeeeeee = op mode screen rows on(1) or off(0), rows top to bottom are bits low order to high order	1
7537 - 753D	30008 - 30014	Reserved					7
753E - 753E	30015 - 30015	User Settings Flags	UINT16	bit-mapped	--g--nn srp--wf-	g = enable alternate full scale bargraph current (1=on, 0=off) nn = number of phases for voltage & current screens (3=ABC, 2=AB, 1=A, 0=ABC) s = scroll (1=on, 0=off) r = password for reset in use (1=on, 0=off) p = password for configuration in use (1=on, 0=off) w = pwr dir (0-view as load, 1-view as generator) f = flip power factor sign (1=yes, 0=no)	1
753F - 753F	30016 - 30016	Full Scale Current (for load % bargraph)	UINT16	0 to 9999	none	If non-zero and user settings bit g is set, this value replaces CT numerator in the full scale current calculation.	1
7540 - 7547	30017 - 30024	Meter Designation	ASCII	16 char	none		8

Modbus Address							# Reg
Hex	Decimal	Description ¹	Format	Range ⁶	Units or Resolution	Comments	
7548 - 7548	30025 - 30025	Reserved				dddd = reply delay (* 50 msec)	1
7549 - 7549	30026 - 30026	COM2 setup	UINT16	bit-mapped	----dddd -ppp-bbb	ppp = protocol (1-Modbus RTU, 2-Modbus ASCII, 3-DNP)	1
754A - 754A	30027 - 30027	COM2 address	UINT16	1 to 247	none		1
754B - 754B	30028 - 30028	Reserved					1
754C - 754C	30029 - 30029	Reserved					1
754D - 754D	30030 - 30030	Reserved					1
754E - 754E	30031 - 30031	Reserved					1
754F - 754F	30032 - 30032	Reserved					1
7550 - 7554	30033 - 30037						5
7555 - 7559	30038 - 30042						5
755A - 755E	30043 - 30047						5
755F - 7563	30048 - 30052						5
7564 - 7568	30053 - 30057						5
7569 - 756D	30058 - 30062						5
756E - 7572	30063 - 30067						5
						Block Size:	68

12-Bit RTU Readings Section

12-Bit RTU Block						read-only except as noted
9C40 - 9C40	40001 - 40001	System Sanity Indicator	UINT16	0 or 1	none	0 indicates proper meter operatio
9C41 - 9C41	40002 - 40002	Volts A-N	UINT16	2047 to 4095	volts	2047= 0, 4095= +150
9C42 - 9C42	40003 - 40003	Volts B-N	UINT16	2047 to 4095	volts	volts = 150 * (register - 2047) / 2047
9C43 - 9C43	40004 - 40004	Volts C-N	UINT16	2047 to 4095	volts	
9C44 - 9C44	40005 - 40005	Amps A	UINT16	0 to 4095	amps	0= -10, 2047= 0, 4095= +10
9C45 - 9C45	40006 - 40006	Amps B	UINT16	0 to 4095	amps	amps = 10 * (register - 2047) / 2047
9C46 - 9C46	40007 - 40007	Amps C	UINT16	0 to 4095	amps	
9C47 - 9C47	40008 - 40008	Watts, 3-Ph total	UINT16	0 to 4095	watts	0= -3000, 2047= 0, 4095= +3000
9C48 - 9C48	40009 - 40009	VARs, 3-Ph total	UINT16	0 to 4095	VARs	watts, VARs, VAs =
9C49 - 9C49	40010 - 40010	VAs, 3-Ph total	UINT16	2047 to 4095	VAs	3000 * (register - 2047) / 2047
9C4A - 9C4A	40011 - 40011	Power Factor, 3-Ph total	UINT16	1047 to 3047	none	1047= -1, 2047= 0, 3047= +1 pf = (register - 2047) / 1000
9C4B - 9C4B	40012 - 40012	Frequency	UINT16	0 to 2730	Hz	0= 45 or less, 2047= 60, 2730= 65 or more freq = 45 + ((register / 4095) * 30)
9C4C - 9C4C	40013 - 40013	Volts A-B	UINT16	2047 to 4095	volts	2047= 0, 4095= +300
9C4D - 9C4D	40014 - 40014	Volts B-C	UINT16	2047 to 4095	volts	volts = 300 * (register - 2047) / 2047
9C4E - 9C4E	40015 - 40015	Volts C-A	UINT16	2047 to 4095	volts	

Modbus Address							# Reg
Hex	Decimal	Description ¹	Format	Range ⁶	Units or Resolution	Comments	
9C4F - 9C4F	40016 - 40016	CT numerator	UINT16	1 to 9999	none	CT = numerator * multiplier / denominator	1
9C50 - 9C50	40017 - 40017	CT multiplier	UINT16	1, 10, 100	none		1
9C51 - 9C51	40018 - 40018	CT denominator	UINT16	1 or 5	none		1
9C52 - 9C52	40019 - 40019	PT numerator	UINT16	1 to 9999	none	PT = numerator * multiplier / denominator	1
9C53 - 9C53	40020 - 40020	PT multiplier	UINT16	1, 10, 100	none		1
9C54 - 9C54	40021 - 40021	PT denominator	UINT16	1 to 9999	none		1
9C55 - 9C56	40022 - 40023	W-hours, Positive	UINT32	0 to 99999999	Wh per energy format	* 5 to 8 digits * decimal point implied, per energy format	2
9C57 - 9C58	40024 - 40025	W-hours, Negative	UINT32	0 to 99999999	Wh per energy format		2
9C59 - 9C5A	40026 - 40027	VAR-hours, Positive	UINT32	0 to 99999999	VARh per energy format	* resolution of digit before decimal point = units, kilo, or mega, per energy format * see note 10	2
9C5B - 9C5C	40028 - 40029	VAR-hours, Negative	UINT32	0 to 99999999	VARh per energy format		2
9C5D - 9C5E	40030 - 40031	VA-hours	UINT32	0 to 99999999	VAh per energy format		2
9C5F - 9C5F	40032 - 40032	Neutral Current	UINT16	0 to 4095	amps	see Amps A/B/C above	1
9C60 - 9CA2	40033 - 40099	Reserved	N/A	N/A	none		67
9CA3 - 9CA3	40100 - 40100	Reset Energy Accumulators	UINT16	password ⁵		write-only register; always reads as 0	1
						Block Size:	100
End of Map							

Data Formats

ASCII	ASCII characters packed 2 per register in high, low order and without any termination characters.
SINT16 / UINT16	16-bit signed / unsigned integer.
SINT32 / UINT32	32-bit signed / unsigned integer spanning 2 registers. The lower-addressed register is the high order half.
FLOAT	32-bit IEEE floating point number spanning 2 registers. The lower-addressed register is the high order half (i.e., contains the exponent).

Notes

- 1 All registers not explicitly listed in the table read as 0. Writes to these registers will be accepted but won't actually change the register (since it doesn't exist).
- 2 Meter Data Section items read as 0 until first readings are available or if the meter is not in operating mode. Writes to these registers will be accepted but won't actually change the register.
- 3 Register valid only in programmable settings update mode. In other modes these registers read as 0 and return an illegal data address exception if a write is attempted.
- 4 Meter command registers always read as 0. They may be written only when the meter is in a suitable mode. The registers return an illegal data address exception if a write is attempted in an incorrect mode.
- 5 If the password is incorrect, a valid response is returned but the command is not executed. Use 5555 for the password if passwords are disabled in the programmable settings.

(continued)

- 6 M denotes a 1,000,000 multiplier.
- 7 Not used.
- 8 Writing this register causes data to be saved permanently in EEPROM. If there is an error while saving, a slave device failure exception is returned and programmable settings mode automatically terminates via reset.
- 9 Reset commands make no sense if the meter state is LIMP. An illegal function exception will be returned.
- 10 Energy registers should be reset after a format change.
- 11 Not used.
- 12 Not used.
- 13 Not used.
- 14 All 3 voltage angles are measured for Wye and Delta hookups. For 2.5 Element, Vac is measured and Vab & Vbc are calculated. If a voltage phase is missing, the two voltage angles in which it participates are set to zero. A and C phase current angles are measured for all hookups. B phase current angle is measured for Wye and is zero for other hookups. If a voltage phase is missing, its cu angle is zero.
- 15 If any register in the programmable settings section is set to a value other than the acceptable value then the meter will stay in LIMP mode. Please read the comments section or the range for each register in programmable settings section for acceptable values.

