

TCA -W2, -W3, -W4 BRACKETS

INSTALLATION AND SERVICING INSTRUCTIONS

[LINK TO PRODUCT PAGE](#)

Installation Instructions

TCA-W2:

1. Orient the crossarm bracket on the wood pole and simply secure the structure using $\frac{5}{8}$ " diameter lag screws (by others) thru mounting holes (A)

TCA-W3 & TCA-W4:

1. Follow step 1 above.
2. Attach the support braces to the crossarm using the $\frac{1}{2}$ " bolt, nuts and washers as shown. Fasten the braces to the wood pole with a $\frac{5}{8}$ " diameter lag screw (by others) thru mounting hole (B)

