

Panel Conversion Kit

1. Install adapter into corner of enclosure by placing adapter over enclosure stud as shown. Install M8 flanged nut and torque to 99 in-lbs (11 Nm).
2. Place flat washer over stud on adapter.
3. Install panel. (order separately)

