

9 0086 24

24 cm = 9½"



GEFLÜGELSCHERE, INNENLIEGENDE FEDER POULTRY SHEARS, INTERNAL SPRING . CISEAUX À VOLAILLE, RESSORT INTÉGRÉ . TRINCIAPOLLO, CON MOLLA INTERNA . TIJERAS PARA AVES, RESORTE INTERIOR

9 0082 21

21 cm = 8½"



KÜCHENSCHERE, GESCHMIEDET, ZERLEGBAR KITCHEN SHEARS, FORGED, DETACHABLE . CISEAUX DE CUISINE, FORGÉS, DÉMONTABLES . FORBICI DA CUCINA, FORGIATE, SMONTABILI . TIJERAS DE COCINA, FORJADAS, DESMONTABLES

9 0084 20

20 cm = 8"



KÜCHENSCHERE, GESTANZT KITCHEN SHEARS, STAMPED . CISEAUX DE CUISINE, ÉTAMPÉS . FORBICI DA CUCINA, STAMPATE . TIJERAS DE COCINA, ESTAMPADAS

9 1091 12

Ø 12 mm = ½"



9 1091 25

Ø 25 mm = 1"



FRUCHTAUSSTECHER PARISIAN SCOOP . EMPORTE-PIÈCE POUR FRUITS . SCAVINI PER FRUTTA . CUCHARILLA PARA FRUTAS

9 1092 00

Ø 22 + 25 mm = ¾" + 1"



FRUCHTAUSSTECHER, DOPPELT PARISIAN SCOOP, DOUBLE . EMPORTE-PIÈCE POUR FRUITS, DOUBLE . SCAVINO PER FRUTTA, DOPPIO . CUCHARILLA PARA FRUTAS, DOBLE

9 1097 00



ZITRONENSCHABER LEMON ZESTER . ZESTEUR . RASCHIALIMONI . RALLADOR DE LIMONES