



Stainless Steel Fry Pan Sartén para freír

ITEM # DIM (WXH)

Natural finish. | Acabado natural.

5734048 8 x 1.6" / 20 x 4 cm

5734050 9.5 x 2" / 24 x 5 cm

5734051 11 x 2" / 28 x 5 cm

With helper handle | Con mango

5734052 12.5 x 2" / 32 x 5 cm

5734054 14 x 2.4" / 36 x 6 cm

Teflon Select® Non-Stick Coating
Revestimiento antiadherente Teflon Select®



5734058 8 x 1.6" / 20 x 4 cm

5734060 9.5 x 2" / 24 x 5 cm

5734061 11 x 2" / 28 x 5 cm

5734062 12.5 x 2" / 32 x 5 cm

5734064 14 x 2.4" / 36 x 6 cm

Ergonomic handles
for comfort and
ease of use.

*Remaches
descentrados para
una sujeción
superior
del asa.*



Sauce Pans Include cover.

Ollas para salsas
Incluye tapa.



ITEM #	CAP	DIM (WXH)	REPLACEMENT COVER CUBIERTA DE REPUESTO
5734032	2 QT / 1.89 L	6.3 x 3.9" / 16 x 10 cm	5734116
5734033	3.5 QT / 3.31 L	7.9 x 4.3" / 20 x 11 cm	5734120
With helper handle Con mango			
5734034	4.5 QT / 4.25 L	7.9 x 5.7" / 20 x 14.5 cm	5734120
5734035	5.3 QT / 5 L	9.4 x 4.5" / 24 x 11.5 cm	5734124
5734037	7.6 QT / 7.2 L	9.4 x 6.5" / 24 x 16.5 cm	5734124
5734040	10 QT / 9.5 L	11 x 6.3" / 28 x 16 cm	5734128

Sauté Pans Include cover.

Sartenes para saltar
Incluye tapa.

ITEM #	CAP	DIM (WXH)	REPLACEMENT COVER CUBIERTA DE REPUESTO
5734185	5 QT / 4.75 L	11.8 x 3" / 30 x 7.5 cm	5734130
5734187	7 QT / 6.75 L	13.4 x 3.3" / 34 x 8.5 cm	5734134

