


REGENCY
INST-A-SOCK™

- Keeps food intact for better flavor and easy removal
- Ideal for pressure cookers, slow cookers and soup pots



11220 •
Inst-A-Sock™
Cotton, 24" x 2" x 8" (set/3)

BAG WELL™
SEALABLE BAG HOLDER

- Securely holds up to 1-gallon food storage bags
- Keeps hands free for other tasks like scooping and spooning food
- Dishwasher safe




1355 •
Sealable Bag Holder
PP, 5" x 5" x 7 1/4" (cd)



PLINK®
DRINKWARE DESCALER & CLEANER

- Descales, restores, and shines coffee pots, coffee machines, stainless steel travel mugs, water bottles, and more



9032 •
Drinkware Descaler & Cleaner
(cd/5)




9032PRO •
Drinkware Descaler & Cleaner
(disp/12)

PLINK®
DISHWASHER FRESHENER & RINSE AID

- Freshens and prevents spots
- Keeps dishwasher smelling fresh between cycles



9033 •
Dishwasher Freshener & Rinse Aid
(cd/2)



9033PRO •
Dishwasher Freshener & Rinse Aid
(disp/12)