


MRS. ANDERSON'S BAKING®  
SILICONE PASTRY BRUSH

- Flexible, shed-proof bristles glide without dragging dough out of shape
- Heat-safe silicone bristles (to 446°F)
- Use to grease baking pans evenly, brush on egg wash, glaze baked goods, and more
- Translucent handle
- Dishwasher safe




**22106** •  
Silicone Pastry Brush  
Silicone/PP, 8.5" x 1.5" (cd)



MRS. ANDERSON'S BAKING®  
12" DISPOSABLE PASTRY & ICING BAGS

- Set of 12 disposable bags for decorating cakes, filling pastries, and more
- Use with or without decorating tips (not included)
- Thick anti-burst material
- No coupler needed



**22095** •  
Disposable Pastry & Icing Bags  
PL, 12" (bx/12)



MRS. ANDERSON'S BAKING®  
MULTI-LAYER CAKE SLICER

- Cut even layers for beautiful cakes and tortes
- Expands to fit cakes from 9" to 12"
- Multiple slots to slice from 2 to 7 layers
- Made from stainless steel
- Dishwasher safe



**38040** •  
Multi-Layer Cake Slicer  
SS, 9.25" x 11.75" (bx)

HOT COCOA BOMB MOLDS

- Make chocolate spheres filled with cocoa, marshmallows, and more for perfect hot cocoa bombs
- Makes 12 halves for 6 filled spheres (2.65" diameter)
- Sized perfectly to fit standard mugs
- Easy and fun to make, customize, and gift



**43906** •  
Hot Cocoa Bomb Molds  
European-Grade Silicone,  
9.75" x 6.5" x 1.25" (bx/2)