

DECORATING



PASTRY BAGS

- For cake decorating, lettering, piping icing, and filling baked goods with pastry cream
- Cut end to fit larger decorating tips – use a coupler to secure smaller decorating tips
- Heat safe to 212°F



93259 •
Reusable Pastry Bag
Cotton / PL, 12" (cd)



93260 •
Reusable Pastry Bag
Cotton / PL, 14" (cd)



93261 •
Reusable Pastry Bag
Cotton / PL, 16" (cd)

DECORATING TIPS

- Includes 27 decorating tips, standard coupler, flower nail and storage box
- Dishwasher safe



38024 •
Pastry Decorating Set
27 Tips, 18/8 SS (bx)

- Tips include writing, flower, bizmark, pastry, and star
- Dishwasher safe



38025 •
Pastry Decorating Set
5 Tips, 18/8 SS (cd)

DISPOSABLE DECORATING SET

- Easily top foods with frosting, whipped cream, mashed potatoes, and more
- BPA Free

Includes:

- 24 disposable 12" decorating bags
- 3 reusable decorating tips
- Big star
- Little star
- Writing tip



7045 •
Disposable Decorating Bag Set
PL (bx)

