

9 1094 00

7 cm = 3"



9 1096 00

6 cm = 2½"



AUSTERNÖFFNER OYSTER OPENER . COUTEAU À HUÎTRES . APRIOSTRICHE . ABRIDOR DE OSTRAS

9 1076 00

10 x 6,5 cm = 4" x 3½"



FISCHSCHUPPER FISH SCRAPER . COUTEAU À ÉCAILLER . COLTELLO SQUAMA PESCE . DESCAMADORA DE PESCADO

9 0152 16



GRÄTENZANGE FISHBONE TONGS . PINCE À ARÊTES . PINZA PER LISCHE DI PESCE .
TENAZA PARA ESPINAS DE PESCADO

9 0154 13



GRÄTENPINZETTE FISHBONE TWEEZERS . PINCE À ARÊTES . PINZETTA PER LISCHE .
PINZAS PARA ESPINAS DE PESCADO

9 0081 20

20 cm = 8"



FLOSSENSCHERE, BLÄTTER VERNICKELT FIN SHEARS, BLADE, NICKEL-PLATED . CISEAUX À NAGEOIRES,
LAMES NICKELÉES . FORBICI PER PESCE, FOGLI NICKELATI . TIJERAS PARA ALETAS DE PESCADO, HOJAS NIQUELADAS