

PIE GADGETS



ORIGINAL PIE CRUST SHIELD

- No more burnt crusts!
- Simply place Pie Crust Shield over the pie crust and place the pie in the oven and bake
- Specially designed to fit larger-handled pie plates



104 •
Mrs. Anderson's
Pie Crust Shield
AL, For 9" Pies (cd)



109 •
Mrs. Anderson's Original
Pie Crust Shield
AL, For 9 1/2" and 10" pies (cd)

PIE CRUST BAG

- Say goodbye to messy countertops and sticking crusts
- Roll crust inside bag for precise shape and size, every time



7406 •
Pie Crust Bag, PL, 11"

7407 •
Pie Crust Bag, PL, 14"