

# ASSORTED ACCESSORIES


## FRY PRESENTATION



**Fry Presentation Bucket-Round w/Handle  
No. FB-15**  
H5 $\frac{1}{8}$  WL3 $\frac{1}{2}$  L6 $\frac{3}{4}$  (including handle)  
1 doz./7# • .9 cu. ft.



**Fry Presentation Basket-Rectangle w/Handle  
No. FB-16**  
H2 $\frac{1}{2}$  L10 $\frac{1}{8}$  W5 $\frac{1}{8}$   
(L14 including handle)  
1 doz./13# • 1.5 cu. ft.



**5" Square Fry Presentation Basket w/Handle  
No. FB-17**  
H2 $\frac{3}{4}$   
3 doz./11# • .4 cu. ft.

## COUNTRY WIRE



**5 $\frac{1}{2}$ " x 4 $\frac{3}{8}$ " Pail w/Handles  
No. CWB-10**  
H5 $\frac{1}{4}$   
1 doz./5# • .6 cu. ft.



**11 $\frac{1}{2}$ " x 6 $\frac{1}{4}$ " Bread Basket w/Handles  
No. CWB-15**  
H6 $\frac{1}{4}$   
1 doz./7# • 2.4 cu. ft.

**7" x 5 $\frac{1}{8}$ " Pail w/Handles  
No. CWB-11**  
H5 $\frac{1}{2}$   
1 doz./5# • .8 cu. ft.

## COUNTRY WOOD

### Country Wood Care and Handling

- Never place food directly onto servers or risers; always utilize complementary serving accessories.
- Clean with a damp cloth or rinse quickly under running hot water. Dry immediately.
- Never soak in water.
- Never clean in a dishwasher.



**5 $\frac{1}{2}$ " x 7 $\frac{3}{4}$ " Country Wood Riser-Square  
No. CRW-15**  
H5 $\frac{1}{2}$   
2 pcs./2# • .5 cu. ft.



**6 $\frac{1}{4}$ " x 10 $\frac{1}{4}$ " x 4 $\frac{1}{4}$ " Country Wood Riser-Rectangle w/Handles  
No. CRW-16**  
H4 $\frac{3}{8}$   
2 pcs./2# • .4 cu. ft.



**8 $\frac{3}{4}$ " x 7 $\frac{3}{4}$ " Country Wood Riser-Square  
No. CRW-14**  
H8 $\frac{3}{4}$   
2 pcs./2# • .8 cu. ft.

