



Caring for Wood Peels

Want to keep your wood peel looking fresh? Always wipe it clean with a damp cloth. Never put in dishwasher, soak in water, place under a heat lamp or leave on a hot surface. If your peel warps, leave it with the warp facing up overnight and it should flatten out.

Deluxe Wood Blade Short Handle

- 814 8" W x 9" L Blade, 14" L Overall
(20.3 x 22.9, 35.6 cm)
- 2212 12" W x 13" L Blade, 22" L Overall
(30.5 x 33, 55.9 cm)
- 2414 14" W x 15" L Blade, 24" L Overall
(35.6 x 38.1, 60.1 cm)
- 2616 16" W x 17" L Blade, 26" L Overall
(40.6 x 43.2, 66 cm)

Deluxe Wood Square Blade – 39" L (99.1 cm) Overall

- 1139 Blade, 11" Sq. (27.9 cm)

Deluxe Wood Long Blade – 6 1/2" L (16.5 cm) Handle

36" L (91.4 cm) Overall

- 836 Blade 8" W x 29 1/2" L (20.3 x 74.9 cm)
- 1636 Blade 16" W x 29 1/2" L (40.6 x 74.9 cm)
- 1836 Blade 18" W x 29 1/2" L (45.7 x 74.9 cm)

42" L (106.7 cm) Overall

- 1842 Blade 18" W x 36" L (45.7 x 91.4 cm)
- 2242 Blade 22" W x 36" L (55.9 x 91.4 cm)

