

8 1160 00

L = 43 cm . B = 32 cm . H = 6 cm  
L = 17" . W = 12½" . H = 2½"



MAGNETKOFFER, OHNE BESTÜCKUNG MAGNETIC CASE, EMPTY .  
MALLETTE MAGNÉTIQUE, VIDE . VALIGETTA MAGNETICA, VUOTA . MALETÍN MAGNÉTICO, VACÍO

8 1176 01

L = 49 . B = 36 . H = 11 cm  
L = 19½" . W = 14" . H = 4½"



KOCHKOFFER »PROFESSIONAL« MIT 2 MAGNETEINLAGEN, OHNE BESTÜCKUNG CHEF'S SET »PROFESSIONAL« WITH  
2 MAGNETIC INSERTS, EMPTY . MALLETTE DE CHEF « PROFESSIONAL », AVEC 2 INSERTS MAGNÉTIQUES, VIDE .  
VALIGIA PER CUOCO »PROFESSIONAL« CON DUE INSERTI MAGNETICI, VUOTO . MALETIN PARA COCINERO »PROFESSIONAL«  
CON DOS SOPORTES MAGNETICOS, VACÍO

8 1010 00-01

L = 48 cm . B = 25 cm  
L = 19" . W = 10"

**D –**

- ⊕ Zwei Fächer für 34 Messer und Werkzeuge
- ⊕ Ein Fach für Bücher und Schreibutensilien

**GB –**

- ⊕ Two compartments for 34 knives and ancillary items
- ⊕ One compartment for books and pencils

**F –**

- ⊕ 2 compartiments pour 34 couteaux et outils
- ⊕ 1 compartiment pour livres et matériel d'écriture

**I –**

- ⊕ Due scomparti per 34 coltelli ed attrezzi
- ⊕ Uno scomparto per libri e penne

**ES –**

- ⊕ Dos compartimentos para 34 cuchillos y utensilios
- ⊕ Un compartimento para libros y útiles de escribir



KOCHTASCHE »CULINARY BAG«, OHNE BESTÜCKUNG KNIFE BAG »CULINARY BAG«, EMPTY . SAC CULINAIRE « CULINARY BAG »  
EN TEXTILE , VIDE . BORSA PER CUOCO »CULINARY BAG« , VUOTA . MALETIN PARA COCINERO »CULINARY BAG«, VACÍO