

# TABLEWARE



- Keeps 4 ounces of butter fresh and soft for spreading



**NT333 •**  
Mrs. Anderson's Better Butter Keeper  
Ceramic, 4" x 3 1/2", 4 oz. (bx)

- Features knob to easily lift lid
- Classic design matches with any setting



**79404 •**  
Butter Dish  
Porcelain, 7" x 3 1/2" x 2 1/4" (bx)

## CORN SERVER



**NT303 •**  
Corn Dish  
Porcelain, 9 1/2" x 4 1/4"

## SALT & PEPPER



**79403 •**  
Salt & Pepper  
Porcelain, 3" (set/2)

## SALT CELLAR



**NT334 •**  
Salt Cellar with Spoon  
Porcelain, 4" x 3" (bx)

## OLIVE OIL



**NT337 •**  
Olive Oil Bottle  
Porcelain, 8 1/2", 16 oz.



**NT338 •**  
Olive Oil Dipping Dish  
Porcelain, 5"

## OLIVE TRAY



**NT16 •**  
Olive Tray  
Porcelain, 15 3/4"