



G. SIERRA SQUARE BAKERY CASE

ITEM 3610 | 21Wx17Dx23¼H



H. WESTPORT DISPLAY CASE

Includes 3 – 13" x 18" Black Acrylic Trays.
Self and Attendant Serve with 3 Tray Positions.

ITEM 815-52 | 21Wx16¾Dx18½H

ITEM 325-13-13 | Replacement Tray



I. ASPEN BAKERY CASE

Featuring 3 Hinged Doors For Easy Access.
Accessories Sold Separately.

ITEM 22414-110 | 20¾Wx15¼Dx22H



Features a reversible design for self or attendant serve!
Featuring 3 different tray positions: tilted front, tilted back, and level.

J. PORTLAND CASE DISPLAY

Includes 3 – 13x18 Clear Trays.

Self and Attendant Serve with 3 Tray Positions.

ITEM 4112-13 | 19½Wx14½Dx20½H



K. IRON DISPLAY CASE

Straight Front for Self or Attendant Serve.
Includes 3 Clear Trays.

ITEM 1735-1318 | 19Wx15Dx21¼H | 13x18 Trays

REPLACEMENT TRAYS

ITEM 325-13-12 | Replacement 13x18 Tray

L. BAMBOO BAKERY DISPLAY CASE

Includes 3 – 13" x 18" Clear Trays.
Self and Attendant Serve with 3 Tray Positions.

ITEM 284-60 | 21Wx16¼Dx22½H

ITEM 325-13-12 | Replacement Tray

