

Toaster Accessories

	Model No.	Description	Shipping Info	
			lb. (kg.)	cu.ft. (cu.m)
	196-12	Release Sheet for 197/297 (5 mil thick) (*2-pack)	.50 (.23)	.07 (.01)
	197-260	Release Sheet for 197/297 (3 mil thick) (*2-pack)	.50 (.23)	.07 (.01)
	299-061s	Release Sheet for CTS Series for W,WS & M (*1 pack)	.50 (.23)	.07 (.01)
	301-062S	Release Sheets for CTD, 2-pack	.50 (.23)	.07 (.01)
	302-030S	Release Sheets for CTDE, 2-pack	.50 (.23)	.07 (.01)
	299-063s	Silicone Belt for CTS Series Toaster (Qty 1)	1.0 (.45)	.07 (.01)
	301-079S	Silicone Belt for CTD Series Toaster (Qty 1)	.50 (.23)	.07 (.01)
	302-029S	Silicone Belt for CTDE Series Toaster (Qty 1)	1.0 (.45)	.07 (.01)
	511	Top Mount Bun Dresser for 297 Series Toaster	3.80 (1.72)	.46 (.01)
	511-140	Top Mount Bun Dresser for CTS Series Toaster, recommended for use with Wire and Silicone Belt models only	3.80 (1.72)	.46 (.01)
	511-141	Top Mount Bun Dresser for CTDE Series Toaster, recommended for use with Wire and Silicone Belt models only	3.80 (1.72)	.46 (.01)
	511-142	Top Mount Bun Dresser for CTD Series Toaster, recommended for use with Wire and Silicone Belt models only	3.80 (1.72)	.46 (.01)

*Denotes number of pieces per single unit.

Single Chamber Toaster

	Model No.	Description	Electrical Requirements	Plug Config.	Shipping Info	
					lb. (kg.)	cu.ft. (cu.m)
	464-B	Single Chamber Toaster	208-240V, 50-60Hz, 3030-4030 Watts	NEMA L6-30P	36.5 (16.6)	3.43 (.10)