

FISH SPATULA

- Angled front edge gently slides under to lift and turn even the most delicate fish without breaking it apart



43756 •
Fish Spatula Rosewood
18/8 SS, 11 1/4" (cd)

SILICONE FISH SPATULA

- Non-stick silicone fish spatula designed to lift and turn the most delicate fish



43744 •
Fish Spatula
Silicone/SS, 11" (cd)

CRAB SCISSOR


- Cut hard shells and separate legs and claws for easier access to delicate meat inside
- Serrated blades prevent food from slipping
- Japanese stainless steel blades (2 5/8" long)
- Dishwasher safe



43810 •
Crab Scissor
SS/ABS, 6 1/4" x 3 1/4" (cd)

SEAFOOD TOOL


- All-in-one tool
- BPA Free
- Dishwasher safe



43816 •
Crab Hammer
PL, 7 1/4" x 1 1/4" (cd)

SHRIMP DEVEINER

- Splits shell and removes the vein in one motion



509 •
Shrimp Deveiner
PL, 8" (cd)

LOBSTER PICK & SCOOP


- Designed to easily remove hard-to-reach meat from the shell after cracking



EG-1 •
Lobster Pick & Scoop
SS, 8"

LOBSTER CRACKER

- Cracks hard shells with ease



43107 •
Lobster Cracker
AL, 5 1/2" x 2 1/4" (cd)

FISH SCALER

- Fun fish design removes fish scales



43676 •
Fish Scaler
AL, 8 1/2" (cd)

CRAB MALLET

- Weighted to crack shells easily



CM-8 •
Crab Mallet
WD, 7 3/4"