

INDUCTION COOKWARE & ACCESSORIES

Divided Casserole Pan w/Cover

3.75 qt./ 3.5 L
14.75"W x 11.75"D x 4.75"H

White
8258-2/30/2

Bronze
8258-7/30/2

Titanium
8258-8/30/2

Replacement Cover
356-21/30M



Square Casserole Pan w/Cover

4.0 qt./ 3.8 L
13.75"W x 10.5"D x 5.75"H

White
8268-2/28

Bronze
8268-7/28

Titanium
8268-8/28

Replacement Cover
368-21/28M



**NEST 2 SQUARE PANS &
FILL BOTTOM PAN WITH
WATER FOR MOIST HEAT**

Shallow Oval Roaster w/Cover

3.0 qt./ 2.8 L
17.0"W x 10.5"D x 5.0"H (2.5" without cover)

White
8265-2/38

Bronze
8265-7/38

Titanium
8265-8/38

Replacement Cover
365-21/38M



**NEST 2 OVAL PANS & FILL
BOTTOM PAN WITH WATER
FOR MOIST HEAT**

Deep Oval Roaster w/Cover

4.5 qt./ 4.3 L
17.0"W x 10.5"D x 6.0"H (3.5" without cover)

Bronze
8270-7/38

Titanium
8270-8/38

Replacement Cover
365-21/38M



Tray

12.5"W x 10.0"D x 1.0"H
(15.25"W with handles)

Bronze
8260-7/32

Titanium
8260-8/32



Cover/Utensil Holder
9080*3